

out in the bushes shooting at 'em) is days (other than the enemy kooks they are started up and forgotten. for Army outfits in the field these power generators . . . mainly because Just about the biggest headache

electricity. That's why there are genoperated equipment take a lot of erators in every unit. Communications, lights and power-

a week . . . 52 weeks a year in places used - around the clock . . . 7 days like Vietnam, And those generators are getting

much, it's got to have regular main-When any equipment is used that

> eral times a day. tenance . . . every day . . . even sev-

wander off to the PX. Nosiree. tough one. You can't fuel-up and care of a generator, you've got a real So, if you've got the job of taking

plenty of air circulation. out of water puddles, and getting other before-operation checks your power lines are hooked up right. time attention. Before starting up. Drain the fuel filters and do all the see that the oil is OK and that the TM calls for. Make sure she's level, A generator calls for a man's full-

> on the load. Your buddy in the tent gadget that could break your gendown the line might hook up some ear tuned to her purr and your eye erator's back. While she's running, keep your

other one available to switch off to so you can do maintenance. the-clock operation, try to have anif the engine's starting to use oil. When your generator is on an aroundhours of operation . . . more often Check the oil level every 3 or 4

py . . . and your outfit ready to fight. best ways to keep your Old Man hap-Good generator PM is one of the



1 asue No. 176 1967 Series THE PREVENTIVE MAINTENANCE MONTHLY IN THIS ISSUE

FIREPOWER 2-19

M55 Quad 50's 2:14 2-14 M108 SP Howitzer Hawk Notes 16-19

55



VRC-12 AF-912 Antenna Fix Antenna Care Soggy Rader Sets 20-21 ARC-518X 22 RWI Cable FSN SUDS TK-115 AN/TRG-24 PRC-6 22

AIR MOBILITY 37-45 Battle Danage New Jack Pub CH-47 Torquing U-6

22222



0744-Series Parts 48-47 M3942-Series 48 5-Ten Wrecker 48 **GROUND MOBILITY 46-52** 5-Ton Muttituel 49 Power Cable 49 Hydrostatic Lock 50-52


Property Stock IAR 53-54 PLL Info 55-59 BIIL 69-61 Tachometer 62 Techameter 62 PLLTM Change Ignition Timing Light 62 New Publications Supply 14, 15, 17, 18, 19, 22, 24, 26, 27, 37, 39, 41, 42, 43, 45, 46, 47, 48, SS 700-20 PLL TM Change 22222

Use of funds for printing of this publica-tion has been approved by Headquaters, Department of the Army, 19 February 1963. DISTRIBUTION: In accordance with re-quirements submitted on DA Form 12-4.



Bot Half-Mast, DS Magazine, Garl Knoz, Ky.

40121



M20 Trailer

oil); wheel screws and nuts loose, missing; wheel washers missing WHEEL BRACKET

broken, missing; whee SUPPORT — Cracked chain busted, missing bracket wedge and bent; wedge lock pin busted, missing; chain

ing; pads (feet) cracked, bent. screws missing, lock washers missbusted, missing; mounting cap busted, selector is out of action); spring weak, broken (when it's lock pin broken, missing; chain ratchet teeth cracked, busted off (won't let jack raise or lower); JACKS - Selector doesn't work

keep them from going into jacks or drawbar battered (enough to JACK HANDLES - Bent,



and through the M55 so that you know what trouble spots to look for. The ones

And to help you, here's sort of a travelogue that takes you up, down, around

that need fixing the day after yesterday are set in blue type

"Bottom's up," as they say . . . so let's start with the . . .

maintenance.

make up the M55.

... the M45C mount . . . the M20 trailer . . . and the generator set — all of which

Seems like only yesterday they were burying the 4 M2 .50-cal machine guns The weapons that are too tough to die . . . that's what your M55 quad 50's are.


But the M55 is back on the scene . . . and that means you know what, Right-






FRONT JACK MOUNT

plates and screws loose, missing. knob is released, pin missing; cover binds, doesn't snap into place when be removed, missing, lock doesn't hold, ed, have water inside, drain plug can't REAR JACK BRACKETS — Dented, crack



spring weak,busted; rubber pads chewed up, missing. REAR JACK LATCHES - Bind, don't hold;



and entire assembly loose on knows about tomorrow night. STOPLIGHTS & TAILLIGHTS to hook up to a 1/4-ton utility trailer — just in case you want busted lenses, missing lamps So keep an eye peeled for Not used nowadays, but who

> ARE IMPORTANT WHEN SO'S, KEEP 'EM IN SHAPE




and the box channel.) on rough ground. Instead of drain plugs, of box channel welded across the cordrilled through the bottom of the trailer these trailers have large drain holes ners to help with leveling the weapon have been equipped with short pieces be removed, missing. (Some trailers TRAILER BOTTOM — Drain plugs can't



Not tight; nuts loose, missing; gasket shot, REAR ACCESS DOOR shape, missing; nuts Loose; gasket in bad TURRET BASE DOORS oose, missing


missing.



-(One in each corner TRAILER HOLDDOWNS

REFLECTORS—Busted, loose, missing loose, missing; screws

read, missing. DATA PLATES - Painted over, can't be



shot, missing; nuts loose, missing. FRONT ACCESS DOOR -Loose, gasket

missing: tie rod bent, dented (enough so that jack handles can't be put in); main lunette and auxiliary lunette cracklocking pins and chains busted, missing; missing; tow cable, cable connector and ed; tool box latches don't hold, box DRAWBAR - Screws and nuts loose,



dummy receptacle battered; (keep the

the dummy receptacle).

4





cover loose, off; shell insulation busted; wires BLOCKS—Power cable TRUNNION TERMINAL

down. If you leave them up, but not snapped in place, and then elevate the not using your quad .50's, keep the doors and nuts for doors loose, missing; clips SHIELD ASSEMBLY — Mounting screws don't hold, busted, missing.(When you're

ASSEMBLY? M450



connected; box batter-ed; cover missing.

ers missing; cables

loose, missing; wash-

JUNCTION BOX—Nuts

CHECK

FOOT REST — Twisted out of shape; bracket pins and chains busted, missing.




SEAT — Ripped, pulled busted; adjusting knob go in adjusting holes won't turn, doesn' out of rollers; rollers hold; adjusting shaf bent so that it doesn'

CHECK.



broken.


bend in the sight brace.) mount . . . the doors can put a mean



DIFFERENTIAL SCREWS - Loose, missing



BATTERY PLATE ASSEMBLY —Latches bent, broken; nuts missing; pins and cotter keys broken, missing; clamp bent, busted, rubber pad ripped, missing.






move sideways, bust-CONTROL HANDLESreturn to center posicontrol handles don't in the mount or the trol linkage out of adbroken, missing; coned; grips cracked; con-Trigger switches bind, tion after you release ustment (you can tell rol linkage cotter keys because you get creep



when of the lamps by switch lamp Dented, cracked; PILOT LIGHT BOX box can't be read, ed out, missing (you overheated, lamp burnswitch is turned on, power cable loose in painted over, missing ing them); warning or can make a quick check power drive unit's no ing; overheat lamp lamp burned out, missfiring circuit warning goes on even though ox, insulation torn; doesn't ligh firing circui



switches can't be moved; circuit breaker mounting screws loose, missing; box and cover cracked; electrical cable insulation battered; cable loose switch doesn't work; box cover and Turret drive and sight interlock toggle TURRET DRIVE SWITCH ASSEMBLY —



and nuts loose, missing.

warning plate painter over, can't be chain busted, missing BLY-Pointer missing; contacts bent, broken; cap cracked, CUTOUT PLUG ASSEM missing:

> LEVER-Twisted, bust-DEPRESSION STOP

ed; spring weak, broken;

M450

broken

SPARE LAMP CONTAINER — Missing: tops missing; retaining clips don't hold,

ELEVATION STOP LEVER screws loose, missing boot ripped, missing; - Bent, broken; rubber



SHAFT — Gear teeth

TUBE TORQUE DRIVE

don't mesh with sec-

gear guard missing. tor, burred, broken

SCREWS — Separated from weld, missing. ISM ALINEMENT SET-TRUNNION PARALLEL




needs oil, as your LO — Battered, dry (it TRUNNION FELT SEAL



missing. SHIELDS — Cracked BRACKETS FOR ARMOR



missing cotter keys broken nuts loose; missing; mounting bolts and teeth burred, busted SECTOR — Cracked



nut and screw loose to sector busted off. supposed to be welder missing; nut that's LIMIT STOPS - Lock





ō WHILE YOU ARE EYEBALLING THE MOUNT...
TAKE LOTS OF TIME ON THE MIB SIGHT.

M18 SIGHT CASE — Mounting holders missing; case cover doesn't fit tight; latches don't protective cloth in reflector bracket cork gaskets missing; hold; handle busted.

cracked, sight

spotted

with grease, oil; sight

ASSEMBLY

MOUNT

BRACE

doesn't hold, spring

ock lugs cracked, lock

weak, busted; adapter


& CLAMP (HOLDER

can't be pivoted

M18 SIGHT — Housing



sight cable broken, Brace bent, loose; socket pins missing. missing; grommets loose missing; plates loose; ground SIGHT SUPPORT GROUP loose



crimped, busted, missing. more than 1/2-in deflection); drain pipe drive belts oil-soaked, cracked, frayed shafts burred, busted; wiring frayed; units POWER DRIVE GROUP — Oil leaks; splined loose on bed plate; pulleys loose, burred; busted, out of adjustment (you don't want

SCREWS & NUTS THAT HOLD M45C & W20 TOGETHER - Loose, missing.

spell); rheostat knob be out of action for a for the light you want; binds, can't be adjusted the sight's going to CONNECTORS

REFLECTOR

tect the lenses by keepway your TM tells you)

CABLE

RHEOSTAT

LAMP

tered (go easy when you

busted, connectors bat-

have the sight end of

SNOB BNOB

tor dirty (clean 'em the

locking lever binds, bro the upper housing lock); he locking lever will his

ADAPTER

en; lenses and reflec-

painted; holder mountcracked; slots in holder mount assembly loose

FOCKING

wants to be free of

that goes into holder cracked, painted (part

sulation cracked, cable paint); light cable in-

ckwards (if it is

you're not going to use ing the sight closed if

tright away and stowed

contacts corroded, bent, plug contacts mate), receptacle dirty (where dirty; insulation ripped; ing; reflector shield cap chain busted, miss dirty on inside, missing: of the brace); light plug the cable will come out the cable in your hand busted; protective cap ... too much pull and

PROTECTIVE

5


=


For the

MENT BLOCK mited (don't rewith anything us cloth); rivets ay busted, miss-randwheel can't

PS 168 HAS THE STORY ON THE 50'S-BUT HERE'RE A FEW THINGS WORTH WATCHING:

HORIZONTAL ADJUSTMENT BLOCK GROUP — Cracked, painted (don't remove paint and stuff with anything more abrasive than crocus cloth); rivets loose, missing; cotter key busted, missing; nut loose, missing; handwheel can't be turned; handwheel cotter key broken, missing.





VERTICAL ADJUSTMENT YOKE ASSEMBLY — Yoke cracked; securing pin bent; pin latch doesn't hold; latch spring weak, busted; handwheel can't be turned; handwheel cotter keys broken, missing; locking clamps bent out of shape so much that cotter keys can't go in handwheel holes, busted; yoke cotter key broken, missing (There is no nut at the bottom of the yoke . . . only a cotter

AMMO BOX SUPPORTS

—Guides don't line up
with machine gun feedway, bent, busted; tray
not tightly fastened to
ammo tray support;
trails bent, burred,



AMMO TRAYS—Cracked, can't be mounted on supports; springs weak, busted;

pad cracked, bent; pins bent, broken.

SOLENOID LEAD FOR LOWER WEAPONS — Not fastened to lower rear support, busted.

CLES-Busted, female

SOLENOID

RECEPTA

washer missing from



close or open, missing.

Busted, openings tilled

stud, pin and cotter key broken,

missing; nuts missing

with debris.

2

Keep in mind when you hook up the solenoid cables that you want to mount each cable between the gun and the trunnion. If the cable is on the outside of the gun, it can get battered by the gun's operating handle.

Remember to disconnect the solenoid cables before you remove the guns. More'n one cable has met an early end because a crewman pulled a weapon off the mount without first disconnecting the solenoid cable.

If some guy in your outfit does become a little forgetful and a solenoid cable gets snapped in two, salvage the connectors if they come through unbusted. They can always be used on a new piece of cable.

You also want to go easy when you have a solenoid cable in your mitts—like with one end connected to the mount or gun. Too much pull on the cable can tear the insulation away from the connectors. And that's a short cut to a short.

Generator Set

PS 164 gives you a rundown on what to look for when it comes to portable generator sets... and it's what you want to have in front of you when you check the generator on your M55. In addition, here are some other items to look over





13

CONTROL CABINET—Beat up; cover can't be closed; loose on mounts; data plates and instruction chart can't be read, painted over, missing. (Although you don't use the output receptacles now, you never know what the future holds. So do what you can to keep them from getting battered.)




FUEL TANK—Loose on mount, leaks; strainer broken, missing; cap doesn't fit tight, tabs broken, missing, valve not open, gasket broken, missing; chain busted, missing; drain doesn't work. (Check the fuel lines, too—for leaks, sharp bends and excessive wear.)

GROUNDING STRAP—
Busted, not connected;
nuts, washers missing.



POWER CABLE—Frayed from rubbing; connector battered; fiber disk busted, missing; clamp loose, missing.



CYLINDER COOLING FINS — Loaded with dirt, leaves and the like.



STARTER SWITCH— Doesn't work.



Publications

An M55 crew that's on the ball has these publications on hand:

TM 9-2010, Ch 1 (May 65), Ch 2 (Sep 65), Ch 3 (Feb 66) — M55 Mount

TM 9-1005-209-25P, Ch 1 (May 66) — M55 Mount

TM 9-6140-200-15, Ch 1 (Jul 58) — Storage Battery Maintenance

TM 5-6115-328-15 (Jun 65) — Generator Set

TM 5-6115-328-25P (Feb 65) — Generator Set

LO 9-2010 (Jun 56) - M55 Mount

LO 9-1000-228-12 (May 66) — Small Arms Crew Served Weapons


TB 9-2010-1 (Aug 54) — Loading Aid Kit FM 44-57, Ch 1 (Nov 51), Ch 2 (Jan 55), Ch 3 (Jan 66) — Service Of The Piece

It's also a good idea to get in the habit of looking for loose screws, nuts and bolts whenever you have a break in firing. When you have two guns or more chattering away, you get a mean lot of vibration. One thing that really gets the shakes is the M18 sight.

If you have trouble with loose screws and such, try using lock washers or locknuts that just might be the answer.

You've heard it before . . . and here it comes again keep steam and high-pressure water hoses away from the M55. You may get it clean real fast, but you might also pay a high price later—when you can least afford it.






Uh-huh! Nix! Hold it!

Never stick a round in the chamber of your 105-MM M108 SP howitzer till you've checked to make positive the main sliding shaft has returned to its forward position . . . meaning, you can see 1/4- to 3/10-in of the shaft.

Why not? 'Cause if the shaft doesn't return and you can see space there, watch out! You might get an unplanned shoot-off!



Here's the scoop: If the shaft doesn't come back like it's supposed to, it means the sleeve bearings have worked loose from the solenoid mounting frame of the firing mechanism group and the shaft is stuck to the rear . . . or could be that paint or rust are causing the sliding shaft to seize.

Either way, it forces the contact plunger shoe against the firing plunger and bushing of the cannon breech mechanism. This causes the percussion mechanism to release automatically when you close the breechblock.

What to do? You'll find the poop on fixing this condition on page 33 of EIR Digest TB 9-1000-200-15/12 (Dec 66). An MWO's also in the works on this.


Meantime . . . watch it!



Let's say you're in a place where the humidity is up there... and the stuff in your thermometer can move up and down faster than a Go-Go girl can move in any direction.

So what happens when you operate your Hawk AN/ TPQ-21 simulator station... shut it down for a coupla hours... and then start things humming again?

Right as rain. Rain is what you think it's done on places inside the simulator station—like the connector wells and the plan indicator, window clutter, azimuth comparator and elevation comparator drawers. And when you get moisture around electronic gear you know you can have all sorts of problems.



One way to fight the condensation battle is to run the station in standby instead of completely shutting it down. The heat generated in standby is a big help.

It's also worth turning on the heating system before going into operation until you see that any condensation has disappeared from the connector wells and drawers.

Another thing . . . take a look at the contacts for the plug-in boards every so often. The idea's to get rid of any corrosion you come across.


SEEING RED

You want to see red on the power distribution panel in your Hawk AN/ TPQ-21 simulator station.

In this case, it's red lusterless lacquer, and in the form of ½-in high stenciled letters that read: "DANGER—416 VAC."

You'll find a quart of the lacquer listed under FSN 8010-166-3150 on page 53 of TM 9-4935-501-15P/1 (Jun 66).

The warning goes smack dab below the handle on the panel.




LACKS CRACKS?



It pays to gaze every few days at the brackets that hold the reactor in the high-voltage power supply cabinet on your Hawk AN/MPQ-35 pulse acq radar.


You just might spot a crack or two in the brackets. If the cracks turn into breaks and the reactor drops, the power supply could take a real beating.

So head off possible trouble by replacing any brackets that look like they've had it.





Make the warning loud and clear. On your Hawk AN/MPQ-39 high powered illuminator:



Why? You can get the granddaddy of all pressures built-up in the heat exchanger when you apply external heat to it when it's full of coolant, but not connected to the coolant system. When the lines are disconnected, the coolant's trapped in the exchanger. The coolant expands and with it comes the kind of pressure that can bust the exchanger and batter the HVPS.

So remember the warning . . . and if you're in a hurry to get the HVPS pressure below 90 PSI, run the radar in standby.


THE SQUEEZE IS ON

You want to make the supply people happy?

Before you send out your Hawk missile's guidance section outer shell for repair, be sure it really needs it.

The shells are hard to come by ... and when you put one in for repair and draw one in exchange, the supply system feels the pinch.

So give para 94 of TM 9-1410-500-12 (16 Jul 62) a hard look before deciding any dents, scratches or gouges in any of your shells make 'em unserviceable.



HEAP BIG TROUBLES

Smoke signals may be a way of spreading the word, but the news is bad when you see puffs of smoke coming from the modulator power supply for your Hawk AN/MPQ-37 range-only radar.

It could mean there's an overrated CB-11 modulator plate circuit breaker in the power distribution panel.

The CB-11 circuit breaker that belongs in the panel is rated at 2 amp, 416 VAC, 400 CPS.

If you have something else, send a signal to your support people.





You spurtin' blue flame 'cause you need an electronic chassis or two for your Hawk missile system?

Other outfits are also trying to latch on to replacement chassis. And it's a situation that goes right on up the supply line.

A lot of the blame can be put on the guys who've put chassis that need repairs on a shelf somewhere . . . and maybe forgotten about them. And when a chassis doesn't get repaired and then put back in the supply system, you're going to have shortages.

How're your shelves?

19

COMMUNICATIONS

set before you know it. your AN/PPS-4 or AN/TPS-33 radar the only thing that can sneak up on Soggy, seeping condensation is about

radar equipment down for the 10-count come in with a one-two punch that puts —and a No. 10 radar is something you That Charlie country humidity can

CONDENSATION


I'M GETTING 3805 YB ZAPPED

PM, try this: For real no-sweat (er, condensation)

1. Keep them under cover (like tents, huts, buildings) until you're ready to put 'em



- Operate each set at least two hours a day.
- 3. Remove all fuses from the front panel of ed areas only). Dry the fuses and lusethe Pipsy-4 when it's not in use (in shelterolders with a clean doth when you get



'n

FSN 5920-050-4965 and your 5-amp fuse 5840-211-12 has your 1/s-amp fuse under under FSN 5920-284-6796.) ready to operate. (Change 8 to TM 11-

> If you can't find a covered area for the Pipsystay that way until far as you can. Let it 4, till its radome up as you're ready to use it





6. If you see moisture in your set's range ures. Get the set to your direct support counter or range extension meter windows, you're too late with the preventive measshop for a look-see in order to prevent

SET?

RADAR




7. To help prevent rot and moisture ruin of your CY-2733/PPS-4 rubber bumpers, try



(use a dry, soft cloth and no solvents Keep the inside of the carrying case dry

The gauges spur rubber rot) (this heads off gouge damage to the ions when you insert the set in the case bumpers from the control panel latches. Be sure the radome is facing the cush-



BAD BUMPERS

LET SUPPORT GLUE IN NEW ONES

the bumpers. will prevent the radome from sticking to on the bumpers before inserting the radar A light layer of talcum powder spread



Getting double vision looking at stock numbers for major components of the AN/ARC-51BX radio set? Don't sweat it. Make a note in TM 11-5820-518-20P (Feb 65): FSN 5821-082-3927 is for a RT-742/ARC-51 receiver-transmitter, and FSN 5821-082-3928 is for a C-6287/ARC-51X radio set control.

KEEP YOUR MUD GUARD UP



Overheated receiver-transmitters in your Victory-12 series radio sets can make all kinds of trouble for you. And, the mud and sand of Vietnam are eager to oblige on the overheat score.

Like so:

Splashed mud and sand make their way into the cooling vanes of the RT-246 and RT-524 and keep the blower motor from doing its job. Naturally, you've got to check the vanes often to be sure they're clean. To prevent splashed mud and sand from clogging the vanes and causing overheating, use the radio set's cover wherever feasible. Not only is the cover a good mud guard but it also helps keep out moisture.





COVER IT OR KEEP IT CLEAN

A caution, though: Be sure the cover doesn't block the intake and exhaust ports of the receiver-transmitters. Blocked ports can overheat a lot faster'n dirty vanes.



Dear Editor,

We've come up with a fix for our antennas here in the 25th Division that may be helpful to other units in a similar bind.

The AT-912 antenna elements on our M48A3's break occasionally from whipping against the open hatch cover.

Since the element that breaks (the AT-1096/VRC lower element) is hard to come by at times, we keep communicating with a flexible "splint" that we slide over the element and tape in place. It works fine so long as the center wire of the element isn't severed. Usually, though, it's just the fiber glass cover that's damaged.


What we use till we can get a replacement element is a flexible gas can spout.

We slide the spout down over the break, keeping the break about midway up the nozzle. Then, tape the spout in place from the bottom up. The spout has to be completely taped to prevent R.F. leakage through the metal tube.

In a bind a wooden splint could be used, but you wouldn't have flexibility.

The "splints" do a pretty good job for us while we're waiting for replacements.

Maintenance Personnel 3/4 Cav, 25th Inf. Div.



(Ed Note-Sounds like a real fine way to get the word out, although it has limitations as a permanent fix. I'd say get the replacement soonest for best radio performance.)



When you're told that a portable or vehicle radio set becomes a part of you, remember the antenna's there too.

Take, f'rinstance, an AT-271()/PRC, AT-912/VRC or AS-1729/VRC antenna. It can wind up in the way of, say, a UH-1 helicopter rotary blade and cause all kinds of chaos.

Besides cutting communications real fast when the blade gives the antenna a karate chop, the blow can damage the Huey's go power and anybody in the area could be seriously injured by darting debris.

Your best bet's to keep the radio antenna out of the rotary blade's reach.

DULL SHARP ANTENNA

FRESH!

HONEST, HONEY,


Ramming rabbits on a rough road with a tied-down antenna, like f'rinstance, an AB-15/GR, may be sport, but Army types don't cotton to being poked, punched or jabbed that way.

You can get the point real quick when that long antenna's tied to, say, a short M151 or M151A1 1/4-ton truck.


Your best bet's to dull a lance-like antenna by sticking a fishing cork or beverage bottle stopper over the end of the MS-118A mast section.

To hold 'er snug put a couple or three wraps of tape around it.

Then, whether a guy walks into the antenna in the dark or backs into it during the day, he won't feel like he has been shish kebabed.



CHATTER CHOP OFF CHANGER



Next time you're chattering back and forth on your AN/PRC-25 series radio set and you lose your channel or station, consider this:

Your A10 oscillator in the RT-505 may be your culprit, with replacement of the module the order of the day.

Early model A10's still are in the supply system, but a late model has licked the back-and-forth channel problem.

If you lose your channel or station during intermittent transmission get somebody to level an eveball at the A10. If it's the improved variety, the A10 cover will be stamped with the words "C-17 MOD ADDED." Naturally, you begin to suspect something other than the A10 quick-like.

If the oscillator's not stamped with "C-17 MOD ADDED," replacing the A10 may end your problem soonest.



Dear Half-Mast,

Sure would appreciate it if you'd remind PS readers that their AN/PRC-6 radio sets have to be re-alined whenever they change crystals.

Here in the support shop we aline all PRC-6's we repair on the 51mc crystal. But, when the sets go back to the units they have to be re-alined if the 51mc crystal is not used.

We get some sets back in good working order, but the using unit did not re-aline for the crystal they changed to. Naturally, they thought something was wrong with their sets.

SP5 I. A. A. B.

Dear Specialist I. A. A. B.,

Well said. Users aline their sets per para 12 of TM 11-296 whenever they change crystals. There's a note in the changes to the TM on V1 and V2 tubes that should be heeded, too. Half-Mast

MEBBE HE'LL HAVE BETTER LUCK! Va

Trying to peak the frequency of your radio receiver with commonplace tools can meet with about as much success as a surgeon operating with a machette or pickax.


The receiver, like f'rinstance, a R-108, -109 or -110, will be thrown out of calibration by tinkering with the



variable capacitors. Then, it'll take a ouija board when it comes to figuring out tuning frequencies.

So, your best bet's to keep those pliers, screwdrivers and the like, from between the tuning plates.

This goes for dusting and cleaning time, too. Never force an oversized instrument into the plates 'cause it'll bend them and throw your receiver out of frequency calibration.



KNOB FORCING'LL FLUB FILTERS




Stop at the stops of your AN/TRC-24 radio set's band-pass filter knob or you'll stop communicatin'.

Like f'rinstance, if you heavy hand the filter knobs of filter kits that go in the CY-1344 accessory case too far to the right, the guide slot will slip off its track and throw the Track-24's frequency setting out of whack.

If you pressure your paws too far to the left, the knob's retaining nut will come loose and louse up calibration of the transmitting or receiving frequency. The nut's there to snuggle the knob on the shaft . . . not for torquing it tight.

Your best bet is to keep within the couple or three turns the shaft allows . . . and stop at the stops,

KEEP IT TIGHT



Snug cable connections on radio equipment can prevent water seepage and resulting loss of power or damage.

CABLE FSN FOR RWI

Trying to team up your RT-246 or -524 receiver-transmitter with an AN/GSA-7 radio set control group for radio wire integration? Don't sweat it. CX-7474/U special purpose electrical cable, FSN 5995-985-7561, will do the job like it says in Change 1 (Apr 63) to TM 11-5820-401-10. The CX-7474 is listed in C5995-IL-A (Feb 66) on Page 4.198.



A selected list of recent publications of inferest to Organizational Maintenance Personnel. This is a list compiled from recent Adjutant General's Distribution Center Bulletins, For complete details see DA Pom 310-4 and Ch 4 (15 Dec 66) and DA Pom 310-6 and Ch 3 (Apr 67).

TECHNICAL MANUALS TM 1-OH-23C-6, C3, Mar, OH-23. TM 5-3431-203-15, Feb, Welding Machine, Arc, Inert Gas Shielded (Midstates Med MAG 300 AC/DC T134) FSN 3431-862-6670. TM 5-3800-217-ESC, Mar, Roller Metorized 10-Tan, Galice Med Chief Rod-O-Matic, Buffalo Springfield Mod TM 5-4120-221-15, Feb, Pershing-TM 5-4310-200-25P, Feb, Comprener, Air, T.S. CFM, 175PSI (Champion Proposition Med OEG-458-ENG). TM 5-4310-218-25P, Jun, Compressor, Reciprocating, Air: Gas Driven, 15 CFM, J, 500 PSI Winterized [Joy Mod I SHGPP-MS-1). TM 5-4320-210-25P, Jon, Pemp, Centrifugal, Petroleum; Gas Driven, Skid Mid; 4 In, 175 GPM 560 Pt Head 595 GPM 450 Ft Head (Consolidated Diesel Mod 4093). TM 5-6100-221-ESC, Feb, ESC For Gen Sel, GED, Wheel Mid. Air Cooled, 7.5 KW, 28 V, DC, Allos Polor Mod MC111; Bendix Mod 5982-1-A-1-8. TM 5-6115-294-25P, Feb. Sergeont. TM 3-6613-292-25P, Feb. Gen Set. DED, 150 KW, AC, 240/416 V, 3 Phase, 60 Cycles [Cummins Mod NFH-12G-130KW-ACT. TM 9-1005-243-12, C5, Mar Armoment Subsystem Mô. IM 9-1055-217-20, C3, Feb. 2,75 Inch. RIXMO. TM 9-1400-375-10/2/1, Mor.

TM 9-1430-375-15P/2, Jon, Pershing. TM 9-2300-224-20P/3, C6 PM, Feb, M113A1, Personnel Corrier Families. TM 9-2350-224-20, C2, Feb, Tank Combol-Full Tracked-90-MM Con, MARAT TM 9-4935-254-15, Jan, Nike-Herc. TM 9-4935-378-15P/1, Jon, Fernhing. TM 9-4935-461-15/2, C2, Mar, GML M22. TM 10-500-48, Feb, Airdrop Of Supplies and Equip Rigging 7-Ton Airborne Crone-Shovel And 15- And %-Cubic Yard Crone-Shovel Altuchments TM 10-500-53, Feb, Airdrop Of Supplies & Equip: Rigging Ammo For law And High Velocity Drop. TM 10-3520-202-10, Mar, Shor Repair Shop, Trailer Mid, 2 Wheel, (York Asiro Mod D8700541), TM 10-4230-202-15, Jan, Delousing Outlit, (Johnson Service Co Mod 252 QM) FSN 4230-889-2315. TM 10-7310-201-25P, Dec, Accessory Outlit, Gas Field Range. TM 11-490-4, Feb. Strategic Army. Communication Tacilities Data Station Operation. TM 11-1090-268-13, Jan. (GUO). Starlight Scope, Small Hand-Held Or Individual Weapons, Mtd. TM 11-2300-352-15-3, Feb, Installa-lion Of Radio Set AN/VRC-49 In M37 Millon Carpo Truck. TM 11-2300-355-15-2, Feb, Installanon Of Radio Set AN/YRC-12 Or AN/YRC-47 in M113 Or M113A1 AFC TM 11-2300-355-15-6, Feb, Installalion of Radio Set AN/VRC-46 Installation Unit When Three Radio Sets AN/VRC-46 Are Required for Curbside Installation in Corrier, Personnel, Armored, MIII Or MIIIAI, TM 11-5805-358-15, Jan, AN/TCC-60

TM 11-5805-389-15, Mer, AN/MTC-10 Central Office Group Telephone. TM 11-5815-331-14, Feb, AN/VSC-2 Redio TT Set. TM 11-5820-590-12-1, Mor, AN/FRC-74B Redio Set. TM 11-5895-367-15, Jan, AN/TRC-103 (V), Redio Terminal Set.

TECHNICAL BULLETINS

TB 9-1400-375-25, Jan, Pershing.
TB 9-1400-425-25, Feb, Redeye.
TB 9-1400-500-25, Feb, Howk.
TB 9-1425-500-25, Feb, Howk.
TB 38-750-2, Feb, Equip Record Main!
Management, Medical Service.
TB 55-1520-214-20/6, Apr., OH-6.

MODIFICATION WORK ORDERS

MWO 55-1510-201-20/1, C1, Mor,
U-E,
MWO 55-1510-204-34/37, C1, Apr,
OV-1,
MWO 55-1510-204-34/47, C1, Apr,
OV-1,
MWO 55-1510-204-34/48, C1, Mor,
OV-1,
MWO 55-1510-204-34/63, Mor,
OV-1,
MWO 55-1510-204-40/3, Apr, OV-1,
MWO 55-1520-203-40/3, Apr,
CH-37,
MWO 55-1520-204-40/2, Mor,
OH-13

MISCELLANEOUS

AR 220-1, Feb, Unit Readiness.

DA Cir 750-19, Mar, Implementing Instructions for Commercial Vehicles.

DA Pum 310-6, C3, Apr, Index to Supply Calalogs and Supply Manuals.

FM 23-82, C1, Mar, 106-mm Recalliess Rille, M40A1.

LO 10-3510-208-12, Jan, Lawrdry Unit, Army Type M532 (EIDAL ELT91).

DA FORM 12-31 WRITE-IN ITEMS

Telephone Terminal Set.

Here are the authorized "write-in" items on DA Form 12-31 for the Helicopter Armament Subsystems. Use page 2, Section 1 of the form.

> 7.62 MM Machine Gun XM27E1 40 MM Grenade Launcher 7.62 MM Gun XM41 30 MM Gun XM30

This 12-31 takes the same route as the original one. Companies, batteries, etc. should forward the form to the next higher headquarters. And don't forget your account number.



A Mounty Shakedown





























IF YOU WANT TO DISPLAY THIS CENTERPIECE ON YOUR BULLETIN BOARD, OPEN STAPLES, LIFT IT OUT AND PIN IT UP








































You say your Huey (UH-1B, D) engine fuel filter assembly, FSN 2915-011-1518, is clogged up with gunk and you need to put in a new filter?

Hold one before you order the whole filter assembly. The assembly was only for modification kits and it'll cost Uncle 100 smackers!


All you need is the \$3.37 replaceable filter element and the O-ring packings. These two items come in filter assembly repair kit, FSN 2945-019-0280, P/N 204-2490-1.

This kit can also be used to replace the external filter of the transmission oil

system. **FSN** Quantity Item HERE'S WHAT YOU (a) 5330-250-0236 **Packing** 2 GET IN THE (b) 5330-291-3078 **Packing** 1 KIT! (c) 5330-618-1670 **Packing** 2 (d) 5330-726-4153 Packing 1 (e) P/N 204-040-760-13 Element

Use items c, d, and e when replacing the transmission oil filter element, and items a, b, and c on your engine fuel filter replacement jobs.

Where's this kit listed? Right in TM 55-1520-210-20P (Dec 66), fig 256 and







DA FORM 2410,

ONE FOR THE HUB ...

You wouldn't throw away a part that was only partly used up, would you? 'Course not . . . moola down the drain!!

But you'll be doing just that unless you keep the DA Form 2408-16 for your bird up-to-snuff on time-change components.

Take the tail rotor hub on the Huey (UH-1A) as an example.

TM 55-1520-211-20 gives you an overhaul time of 1100 hours. But the yoke has a retirement time of 3300 hours. So if you keep only the hub time the yoke service life will be cut two-thirds. Overhaul types will have to scrap the

DA FORM 2408-16, 1	YOKE T/R	GRIP, T/R	HUB, T/R	- Interconne	130001	
	1-017-010-1401	164-010-706-9	294-010-794-3	- 111	UH-1A	
	82-17412	(9-4712	42-3439	. !		9
I.	3300	1100	1100	150		
	SNUFF?	2408-16	IS YOUR		63-14102	
	Y	3	1			

yoke because they don't know the time. No sweat on the other Huey model hubs.

What to do? Easy, really. Just reach for your copy of TB AVN 23-65 (16 Jan 67) on components requiring maintenance management and historical data. In a few minutes of reading you can be an expert.

In a nutty little nut-shell you need a DA Form 2408-16 for the condition components listed in para 5 and another 2408-16 for the time change components listed in para 6.

By zipping thru para 6 you'll find the tail rotor hub, grip and yoke part numbers listed on pages 32 and 34. Here are the Huey part numbers, for all models, that get listed on your 2408-16.

204-010-784-3 204-010-703-17 204-010-703-21 204-011-701-7 204-011-701-11 204-011-701-13 204-011-701-21	Hub P/N
204-010-706-9 204-010-706-11	Grip P/N
204-010-710-1 204-010-781-1 204-010-781-5 204-010-781-9	Yake P/N

When the overhaul time rolls 'round and you ship the hub back to support be sure you fill out and send along 3 DA Form 2410's—one with the hub time, another with the grip time and a third with the yoke time. No joke . . . this poop is right in para 4 of TB AVN 23-65. Of course, you get the poop for the 2410 from the 2408-16.

When the hub gets to overhaul the grip and yoke are separated from the hub and the yoke can be used again if it doesn't reach retirement time before the next hub overhaul.

ONE FOR THE YOKE ...

ONE FOR THE

GRIP...

Go ahead, pick up the log book on your bird and see if you've got the hub components listed on the 2408-16.

What's that — you find the hub listed but not the grip and yoke? No sweat!

To reconstruct missing records eye para 10b of TB 55-1500-300-25 (Mar 67) on aircraft component replacement and re-use procedures. If you still don't make out, contact AVCOM, ATTN:

Of course this 2410 business is a twoway street. The overhaul types also are supposed to ship 3 2410's to the field ...hub, yoke, grip.

AMSAV-FMM.

So, when a hub comes to you from depot, general support or direct support be sure all copies of the 2410 are with it. You can't enter "hours since new" on your 2408-16 unless you have the paper work.

Get on the horn if you have to, man —hubba, hubba, hubba!

RAINY SEASON?



When the sky opens up and pours cats and dogs, plant life goes on a spree and so does corrosion on bare metal parts of your Huey (UH-1).

Corrosion gremlins may go to work on the stabilizer bar, break down the cadmium plating, eat away and weaken metal to the point of producing cracks. On the highly stressed stabilizer bar cracks lead to crack-ups!

So, next time you mount your charger, eye the bar for cracks 2.1 inches outboard from the tie-rod retaining-bolt. If you spot any cracks, the stabilizer bar assembly gets replaced, pronto!




Vibration is something fling-wing mechanics learn to live with—when it doesn't get out of hand.

F'rinstance, you can tell easily enough if trouble's a-brewing with the main grip bearing in your Charlie-model Huey (UH-1C).

Just level the main rotor and stabilizer bar.

Next, move the bar in either direction. The blade grips should change pitch smoothly and freely. If you get a bind—or hear the bearing grate—better hustle the bird off to direct support for a thorough checkup. It'll save time, parts . . . and loose bicuspids.



The old bit about a mechanic not being able to do a job without tools was never truer than on the Huey (UH-1C) 540 rotor system.

It's a capital idea to inventory your special tools with TM 55-1520-210-20P (Dec 66) and TM 55-1520-210-35P-2 (Jan 67) to make sure you have the new tools needed to maintain your Charlie Model 540 rotor system.

Requisition any missing tools-you bet!





When your bird comes in to roost after a mission be sure you check for battle damage with a fine-tooth comb.

Sure, you can easily locate bullet entrance and exit holes and get them patched right-off. But what about in between? If a hunk of lead creases a fuel, oil, hydraulic or electrical line or control cables and rods you've got a weak part that has to be replaced, pronto.

So, be mighty sure you trace a bullet path to find hidden damage. You wouldn't want a weak part to let go over Charlie territory.






Maybe you overlooked it, but DA Pam 310-4 lists a new pub for Jack, hydraulic tripod, Type B6, P/N 50J25178, FSN 1730-516-2019.

This 10-ton heavy was originally issued only to Shawnee (CH-21) and Army Mule (CH-25) helicopter outfits, but other units may have inherited it.

The pub for this old maintenance standby is TM 55-1730-208-15 (Mar 66). It replaces Air Force T.O. 35A2-2-11-1 and -4 (Dec 57).



TORQUE CHECK

Dear Windy,

Here 'n' there the TM's say to "check" torque on a screw, bolt or nut.

Some guys check torque on nuts by cutting the safety, setting the wrench at the minimum torque called for and making with the muscle. If the nut doesn't turn, or if there's a click, they figure it's got the proper torque.

Others say that to check torque you cut the safety, back the nut off a few turns, then tighten to the proper torque value. In fact, they re-torque the nut.

What say you, Windy?

SSG L. E. M.

Dear Sergeant L. E. M.,


It's nigh-on impossible to check the torque value of a tightened nut because torque indication is good only when the screw, bolt, or nut is moving. You have to start from scratch.

So, to check torque, the nut must be re-torqued. Just back off on the nut to below the minimum torque and then bring it back to the torque given in the maintenance pub.





If your Beaver (U-6) came back from support with an engine chip detector amber caution light, don't sweat it. The amber light replaces the red one to make all bird chip detector lights the same color. Ch 1 (14 Apr 66) to MWO 55-1510-203-34/4 authorized switch.





Para 29a, TM 55-405-8 (Sep 66) says that ground equipment used on landing strips, taxiways, perimeter roads, and aircraft flight areas should be painted yellow for safety reasons.

Does this go for all areas?

SSG C. G. C.

Dear Sergeant C. G. C.,


Nosir-e-e-e, depends on whether you're in a tactical or non-tactical area.


Para 17d, sect V, AR 746-5 (Apr 66) Color and Marking of Army Materiel has the scoop. It authorizes materials handling equipment including aircraft towing, fuel and oil dispensing vehicles used in non-tactical areas to be painted gloss yellow No. 13538, Mil-E-7729.

If you're in a tactical unit this equipment should be painted semi-gloss olive drab No. X24087, Mil-E-52227.

When you make with the yellow, para 23 of the AR says that certain vehicles and equipment may be painted with contrasting stripes to make 'em more readily visible to pilots and drivers of other vehicles.

The AR also spells out what color of contrasting paint you'll use on O D or other dark colored vehicles, or on yellow or light colored ones.






Troublesome exhaust smoke from an M52A2 or other M39A2-series multifuel 5-ton truck can be cut by changing the fuel injector nozzlesfrom the original 1-holers to 2-holers on the LDS-465-1 engine.

MWO 9-2815-210-30/2 (Dec 66) tells how your support can replace the 1-hole nozzles with the type nozzles used in 21/2-ton multifuel engine trucks.

M62, M543 5-TON WRECKER . . .



Full throttle when you're operatin' the crane on an M62 or M543 5-ton wrecker.

Some guys didn't realize this when they read Step 4, page 51, in TM 9-2320-211-10. So the hydraulic pump didn't run fast enough to open the vanes all the way. The vanes got to chattering, and pretty soon the pump went bust.

Now there's no mistaking what the TM means, because, in Ch 2 (Jun 64), it says: "Pull throttle control valve to full open position."



Maybe it's not your master brake cylinder's fault if it's leaking. How about the breather valve in the vent system? Have you got the right one on your 5-ton multifuel engine truck?

MWO 9-2320-211-20/8 (Sep 66) says to replace the original breather with Breather Assembly, Valve, FSN 2520-272-7965.

If you don't have the new breather, you could get a pressure buildup that'll spring a leak in the master cylinder when you hit the brakes.

There's no allowable leakage of the master cylinder. But if you find some moisture in the boot, don't get excited until you've smelled it. It could be rubber preservative put inside the boot in production.



With this cable, I thee wed . . . said SC 4910-IL (Oct 66) to the generator and the shop van.

And the same goes for any unit mounting electrically-powered tool or shop sets in either the M109 (G-742) or M220 (G-749) 2½-ton shop vans. The way to carry the juice from your favorite external power source is with a 7-foot cable which goes by the identification of FSN 4910-395-1995 . . . at a cost of \$16.54 each.

In a lot of shop setups, though, this 7-foot cable won't reach all the way back to the van. So you'll need a 25-footer identified as FSN 4910-395-1994. This one costs \$38.80 each.

Both of these cables are listed on page 49 of SC 4910-IL. So lock cychalls with a supply support man on this arrangement and just watch what it does for your peace of mind (your maintenance mind, of course).

SNEAKY

engine against hydrostatic lock. a 1-lb bag. You get some idea of what happens if you try to run your vehicle's Just try to jam 2 pounds of sugar in

can't go to the top of its compression press like air and gas do. So the piston Liquid—water or fuel—won't comsometimes even in all the cylinders. uid gets into an engine cylinder-Hydrostatic lock happens when liq-

That liquid might's well be rock!

rod'll probably be bent or the piston give. In your engine, the connecting be badly damaged. broken. If the engine isn't ruined, it'll Like the 1-lb bag, something's gotta


FEEL 'ER OUT

keep it from coming back? from bustin' up your engine? What do hydrostatic lock? How do you stop it you do to get rid of it? How do you So how do you know you've got

50 TRYING TO A SIZE 32

> starting 'er up. before getting down to the business of test your engine for hydrostatic lock Like you suspect a booby trap, you

multifuel engine, you hold the engine off. Or, if your truck's got a diesel or stop handle in the "fuel off" position This's done with the ignition switch



CHECKING FOR HYDROSTATIC LOCK IS A MUST. 'IGNITION OFF' OR "FUEL OFF"

The piston with liquid sittin' on top of there was liquid in another cylinder. ignition in a "clear" cylinder when Figure what would happen if you got

> can bet your boots some other part of cylinder head wouldn't give, but you your engine would give. The liquid wouldn't compress and the It would try to compress that liquid it would drive up like a battering ram



IS CLEAR TO FIRE! ... SOMETHING'S GOTTA GIVE! With "ignition WATER IN ONE CYLINDER WHILE ANOTHER

tacts will burn. and firm, the conseconds using the turn the engine you don't press hard the starter switch. If hard but quick on starter. You press over for 2 or 3 off" or "fuel off,"



RELIEVE "INDIGESTION"

If you hear—or feel—a jolting thunk, or if the engine just seems to want to stop turning over, you stop quick. You've probably got hydrostatic lock. Whatever's in there—water or fuel—has to come out. And to get it out you'll need the help of a qualified mechanic.



Spark plugs have to be removed, if you've got a spark ignition engine.

On compression ignition engines, fuel injector nozzles only have to be loosened or removed.

Then you turn the engine over a few times. As the pistons come up, any liquid in the cylinders is dumped out the sparkplug or injector assembly holes.

Make sure, tho, with spark ignition engines that you still have the "ignition off" so there's no chance of a spark jumping to fuel being pumped out.

And flush away any liquid that's been pumped out of your cylinders.

After sparkplugs are replaced, or injector nozzle assemblies tightened back down, your engine should start easily.



H₂O BLUES

Any time you see signs of coolant leaks—drips and seeps, water in crankcase, oil in radiator—sing out for a mechanic to make a close check. Repair or replacement now may save you from hydrostatic lock and even worse troubles later.

FUEL IS FOE TOO

Fuel can be a real Sneaky Pete in setting up hydrostatic lock.

You drop your guard when you forget to turn off all electrical switches. If they're left on after the engine's stopped, fuel could keep pressing against the manifold heater valves. A little leak here over a few hours can give your engine a real bad case of hydrostatic lock.


Bum fuel injector nozzles can lead to hydrostatic lock too, leaking fuel right into the cylinders.

WET BULLET

Getting hydrostatic lock in your truck's engine may be like pulling the trigger at the wrong time in Russian Roulette. The odds are against it—but when it does happen . . . !!!

A few seconds spent checking for hydrostatic lock better the odds against firing a "bullet" into your engine.






A lot of supply men get mixed up when filling out DA Form 444, Inventory Adjustment Report (IAR). Here are the simple rules we give our units for making out property book adjustments.

Use DA Form 444 for:

1. CORRECTING ERRORS IN EQUIPMENT NOMENCLATURE.

For example, when a property book page calls a 1/4-ton truck an M151, instead of an M151A1; a mount, trp, MG, cal .30, M2 is carried as a mount, trp, MG, cal .30, M1917A1, etc.



Pick up the incorrectly identified item on a DA Form 444, and post the IAR action on the property book page.

If two different types or models of authorized equipment (say the M151 and the M151A1) have been accidentally accounted for on one page, make a new page for one of the items, and post the IAR action on the original page, which continues to record the other item.


File a copy of the IAR in the document file after it's been OK'd.



2. PICKING UP INVENTORY OVERAGES.

Make up a DA Form 444 for the items in excess of the quantity listed in the property book and post the IAR to the property book. Turn in excess items.

File the IAR in the document file after it's OK'd, and file the turn-in document when the transaction is completed.




NO IAR

An FSN or a nomenclature change from supply support or from a supply publication doesn't take an IAR. In this case just make the correction on the property book page and note the authority listing the change.

The IAR is not authorized when it's possible that items have been substituted or lost.

The CO, for whom the book is maintained, approves IAR's.




Looks good. And, the IAR takes minimum info when it's used for making minor adjustments in the property book. You can use only whatever blocks and columns are needed to identify and describe the adjustment.

For example, the unit price info doesn't have to be totaled in the "Adjustment Amounts" columns. If you find it helpful, tho, you can use those columns to record the quantity of items you're crediting or charging to your property book.

54

Half-Mast

WHAT CAN YOU PUT ON A PLL...?



To put it another way, any item that's authorized for stockage in your supply or maintenance publications, plus any other items OK'd for organizational maintenance, which rack up demand info (DA Form 2527), are authorized for your PLL.


PLL GUIDES

The basic guides on PLL control are AR 735-35 (Oct 65), Section VI, and your local PLL SOP. And, the CO responsible for the equipment is the approving authority for the PLL. When it's possible, the CO may have his PLL made up by his supply support outfit, but the list is made up for his OK.

ANSWER ... WHAT DO YOU NEED? A GOOD PLL PRESCRIBED LOAD LIST) COVERS SUPPLIES AND REPAIR PARTS AN OUTFIT MUST HAVE ON HAND, SUSTAINED OPERATIONS SUPPLY.

	T BOX IV	RECORD OF DEMAN							
DARE	POCU:	GIT OF	CUMULA- hve DEMANOS	OATE					
6346-013	0	0	1	100					
7017-001	0	0	1	3518					
7038-030	0	0	1	-					

DA FORM 2527






PLL is made up on DA Form 2063-R and takes anything authorized at organizational level to keep your unit shootin', scootin' and communicating. H+HCO PRESCRIBER VOLUMENT THINGS C. Thereside, which LIKE

WABCT 2 13 APRIL 1967 THESE 2 2540-640-2267 BLADE 2910-735-1316 FILTER 1 EA 3 2910-753-9118 CAP EA COMMON & SPECIAL HARDWARE 2 EA 2920-391-4218 DISTR 2 2920-828-01/7 CABLE 2 2920-953-9784 REG 2920-314-0752 MUFFLER EA 3030-849-1033 BELT EA 10 5330-050-3351 NUT IN COME AND A. S. MARCH WILL MINE AND DESCRIPTION COMMUNICATION OF PERSONS AND LOCAL LAST. PRESERVING SUPPLIES 56, Forth 2003 H, 1 Sep 15

PLL SIZE & WEIGHT

The specific items and quantities authorized by equipment parts manuals for your PLL are based on equipment density, which means the overall total of equipment that needs the repair part, maintenance item or maintenance related



Here are some of the main PLL guide lines:

STOCKAGE LEVEL

- 1. TM's list minimum allowances for 15 days of supply.
- On an initial PLL you can stock all repair parts which show a stockage allowance in the TM's.

Some manuals list allowances in round numbers and use equipment density spread columns. To find your PLL allowance you just check the correct column.

Other manuals show an allowance factor and provide a formula to help you work out your PLL allowance. And, if the answer is anywhere from 0.5 to 2.4, you're authorized to stock 2 each of an item on your PLL. If the answer is 0.4 or less, you're not authorized to stock the item on your initial PLL.

INITIAL PLL STOCKAGE


> AS NEEDED ITEMS

3. If your equipment density is too low to allow initial stockage of items listed in either type of manual . . . no sweat. You haven't lost out yet. You can get the items for use as needed, and keep demand records on 'em. Then when an item collects 3 separate demands it can go on your PLL.


AS REQUIRED REPAIR PARTS

 Repair parts listed "as required" or with an asterisk, in TM's, are not authorized on initial PLL, either. You order them as needed and start keeping demand records on 'em, too.





Then you make a DA Form 1543 for the item, jot "DS", the initial allowance, the date, etc., on the form and file it and the item's DA Form 2527 in your PLL file. You put in a request for the item, and tell support the item has been added to your PLL.





list, etc., and add to your PLL whatever the publication authorizes for organizational maintenance stocks.

And, of course, you must always clue supply support when you make any changes on your PLL.

ON-HAND/ON ORDER/ON RECORD

Anything on your PLL must be on hand or on order at all times.

And, you need good demand records so you can easily add to, or adjust your PLL allowances, like AR 735-35, para 6-6 says.

Once your initial PLL is established for an item, your demand records are the authority for your PLL allowances.



Any items on your PLL that run over 200-bucks each, and any recoverable "T" items, you stock only in the quantities listed in the TM's.


You must keep PLL records on these items, too, since they're part of your PLL, but your allowances on such things are fixed . . . you don't change your stockage levels on 'cm, like you do on other things.

TOOLS

And, last but not least, tools, expendable and non-expendable, special and otherwise, are not included on a PLL.

Tool sets and reportable tools are accounted for in the unit property book. And, expendable, non-reportable tools are requested, controlled and accounted for according to local SOP.





Here's the supply deal on repair parts and maintenance in your BIIL (Basic Issue Item List):

Repair parts and maintenance items issued with specific equipment or authorized for the equipment in the operator's manuals, are not necessarily part of your PLL.

Of course, sometimes items issued with, or authorized for use on equipment, are also included on a PLL, but that's because the items are also authorized by the -20P TM used for computing the PLL.

Normally, the BIIL repair parts and supplies are kept on the equipment. But local SOP sometimes OK's storage of the items in some central location. But in any case it's up to the operators to see that the items are on hand or on order at all times.

BIIL RECORDS

No special records are required for on-equipment repair parts and supplies.



The TM or the list authorizing the items for the equipment is used to inspect, inventory, and request replacements.

For aircraft, DA Form 2408-17 is required and contains BIIL items and is used for inspections and inventories.



The request goes through the same supply channels used for replacing PLL items. And, if a BIIL item happens to be on the PLL, it can be replaced from the PLL stocks, and the demand recorded on the PLL records.

A BIIL item, which is not a PLL item, can be added to the PLL when it racks up three separate demands within 180 days (6 current review periods).

The big thing to keep in mind about BIIL maintenance items is that the stuff must always be handy and ready for the equipment it's authorized for.



Well, maybe you aren't testing if you have the Simpson Model TDS tachometer-dwell test set, FSN 4910-788-8549. The tachometer on that test set may not give an accurate reading on the shielded ignition systems.

That inaccurate reading's caused by a capacitor. Take a look at your manufacturer's manual, Fig 3, Item 28, symbol C-10 and you'll see the capacitor that's causing the trouble. That .033 μ f \pm 10% capacitor should be replaced with a .01 μ f \pm 10% capacitor.

If you still have the capacitor that gives the goofy reading, turn your set in to your support, and they'll get the new capacitor and corrected instruction manual from U.S. Army Weapons Command, ATTN: AMSWE-SMD-T, Rock Island Arsenal, Rock Island, III. 61201.

MIGHT BE A REAL SHOCKER ...

YOUR IGNITION TIMING LIGHT


Hold one if you have a power ignition timing light, FSN 4910-500-2135, made by Aimes Engineering Co., Inc., under Contract DA-11-070-AMC-1534(W).

Some of these models have high-voltage leakage through the case, and you can't tell just by looking at it if you have a shocker or not.



To play it safe, take your timing light to your direct support. They'll open it up and look at the terminal strip. It may have a 4-hole terminal strip instead of the needed 5-hole strip.






What's the scoop on preserving wooden handles for pioneer tools, including emergency tools mounted on vehicles? Do we paint 'em, use linseed oil, or what?

SFC W. B.

Dear Sergeant W. B.,


Glad you asked. Gives me a chance to plug TM 5-461 (Jun 66), Engineer Handtools. Paras 7 and 9 give you the lowdown on when you paint and when you don't paint . . . and the rest of the TM gives you good dope on tool use and maintenance.



M20 BA CHECK

If your M20 breathing apparatus (FSN 4240-678-5263) doesn't have a serial number ask for one soonest. You need the number for the BA's TAER's historical records. Just write to CG, U.S. Army Ammunition Procurement and Supply Agency, ATTN: SMUAP-RSB, Joliet, Illinois 60436. You'll get a scrial number and instructions on how to mark it on your BA.

EXPENDABILITY OK



Dear Sergeant S. M.,


Either the SB or an ML is OK. But, it's usually best to use the publication quoted by your support unit since they normally have the latest poop first.


New TOE's (G-series) identify expendable items in Sect III, so they can also be used as expendability authority.

Half-Mast

SPOT PLL TM CH 3

Are you missing Ch 3 (Jul 66) to TM 9-2300-223-20P? Maybe not. You might've misfiled it because it came out mislabeled TM 9-2320-223-20P. You need this change for your current CAOSL (Consolidated Authorized Organizational Stockage List of Repair Parts for Tank-Automotive Materiel).





LSA'S IT FOR MIGAI RIFLES

M16Al riflemen, hear this!

Word's been flashed by the Army Weapons Command that Lubricating Oil, Semi-Fluid, automatic weapons MIL-L-46000A--known as LSA--is the best lube-preservative for your 5.56-MM M16A1 rifle.

Here're the stock numbers for LSA: 4-oz tube, FSN 9150-889-3522; 1-qt can, FSN 9150-687-4241; 1-gal can, FSN 9150-753-4686.

It may be a little scarce to begin with so don't sweat it. Keep on using PL Special (FSN 9150-273-2389...4-oz can) and rifle grease (FSN 9150-754-0063...1-ib can) until you get your LSA.

Remember this: How good a job your lubricants will do for you depends on how often and how well you clean your rifle and apply these lubes. Here's the system found best by test;

- 1. Clean your rifle thoroughly after every firing, like the TM requires.
- Lube the bore and chamber, and the spring in the magazine lightly. Lightly—that means with a clean rag dampened with the lubricant. If you've latched on to some LSA, use it. If not, stick to the PL Special.
- Lube all other metal parts of your rifle with LSA or PL Special.
 The working parts should get generous and frequent applications.
- 4. If you're still using PL Special, don't forget to use rifle grease like it says in the TM. But, after you've switched to LSA, you can forget the rifle grease.
- No matter what lubes you've got, <u>never</u> use any grease or oil on your ammo or in your magazines. Never!

Incidentally, these instructions don't apply to you arctic-type guys. Stick to your low-temperature lubricant (LAW) when firing below zero degrees Fahrenheit.

JULIAN DATE CALENDAR

FOR LEAP YEARS ONLY

Day:	100	Letter	Mar	Age	May	Aut at	May.	Aug	Sep	00	May	Dec	Co
10	001	003	661	093	133	153	383	214	745	275	306	136	
3	560	603	643	093	133	154	384	315	346	176	307	337	5
3	003	034	043	094	134	155	185	276	247	277	364	331	
4	664	608	264	445	135	156	384	217	248	371	300	339	
5	005	034	945	996	135	157	187	316	249	379	110	340	
4	004	002	044	047	107	168	188	338	150	280	311	341	- 1
7	007	938	067	999	128	159	1.89	330	351	387	313	343	- 3
8	994	609	964	999	125	160	190	221	353	262	313	343	
9	004	040	065	100	130	161	191	222	263	283	314	344	- 4
id	919	040	979	101	131	162	192	222	254	234	315	345	15
11	611	042	971	192	132	163	117	224	755	285	314	346	11
12	013	043	073	100	133	194	194	225	256	285	317	947	- 13
15	017	944	973	194	134	165	195	220	257	287	319	345	12
14	014	043	674	105	135	165	195	227	258	255	319	349	14
13	903	049	075	104	134	147	107	220	259	289	320	350	15
16	016	047	975	107	137	160	198	229	250	290	221	351	116
17	417	048	077	100	135	1.59	199	233	259	291	322	357	- 17
10	018	049	078	199	139	170	200	231	243	292	323	353	11
19	014	050	079	110	1.40	171	301	232	263	293	334	354	15
20	030	ast	080	111	140	172	300	233	354	224	325	355	30
91	991	050	081	110	145	173	203	234	345	395	334	354	31
22	022	0.50	047	1111	143	124	204	935	266	294	327	357	33
23	023	054	083	114	144	1.25	205	234	247	297	338	254	53
24	924	955	984	113	145	176	204	937	268	298	339	359	24
25	025	0.56	045	116	144	199	907	238	269	299	333	340	35
26	025	057	986	1117	1.47	178	208	239	920	300	331	361	21
27	927	058	087	110	148	179	209	240	271	301	337	342	20
20	998	939	098	119	149	180	210	241	272	302	333	340	31
29	927	080	009	120	150	181	211	242	270	303	224	344	35
30	000		090	121	151	162	212	243	274	334	335	365	35
31	931		001		137		213	244	and the state of t	303	and the later	366	11

GOT CLUTTERITIS?



If you have anything . . . parts, assemblies or complete pieces of equipment . . . NEEDING REPAIR, turn them in, NOW . . . to the next level of maintenance!! Get 'em repaired, and ready to use!

JULIAN DATE CALENDAR

IPERPEDUALS.

Day	Jon	feb	Mar	Apr	May	fees	July.	Aug	Jep.	Opt	Nov:	Dec	Con
1	001	007	060	071	121	152	387	213	244	274	305	335	
3	003	633	061	092	122	153	143	214	745	275	306	335	- 2
3	000	034	042	093	123	154	384	311	246	776	307	337	- 3
4	004	035	063	094	124	155	145	275	247	277	306	330	- 4
5	005	036	064	095	125	156	185	297	748	278	307	337	- 5
4	664	007	565	096	126	157	107	211	249	279	310	340	. 6
7	007	608	066	097	127	150	100	219	150	280	311	341	7
4	004	039	067	098	176	157	189	220	254	251	312	342	
9	009	040	048	099	129	160	190	221	1222	262	213	343	
10	010	D41	980	100	130	161	191	222	253	282	314	244	10
11	011	047	000	101	121	162	192	223	254	784	315	345	11
13	012	043	071	102	132	163	193	774	. 255	285	316	246	13
13	013	044	077	103	133	164	194	225	250	250	317	347	13
14	614	045	073	104	134	165	195	226	257	787	318	348	14
13	015	044	074	105	135	166	196	227	254	255	319	349	13
14	016	547	073	106	136	167	197	229	259	289	120	150	16
17	617	048	076	107	125	166	198	227	262	290	221	251	17
14	018	DIT.	607	108	138	169	199	200	241	291	333	352	18
19	019	050	078	109	139	170	200	231	342	293	323	353	19
70	979	051	0.79	110	140	121	201	232	263	293	334	254	20
21	601	052	000	300	141	129	202	233	264	29.4	325	055	21
22	022	053	061	112	142	173	200	234	265	295	336	356	22
23	003	054	043	1113	143	174	904	235	244	294	337	357	20
24	024	999	063	114	144	179	205	200	267	297	328	350	74
25	025	950	084	215	145	126	206	237	268	298	329	359	75
25	935	957	065	114	146	177	207	238	269	299	350	350	76
27	937	958	988	117	147	178	200	239	270	900	001	Dati	- 27
78	975	957	987	1118	140	179	207	240	221	301	332	362	19
77	079		088	111	149	180	710	941	979	300	333	343	79
50	000		947	130	150	181	211	240	273	503	334	364	30
31	931		999	-	151	1000	212	243		204	100	345	31

YOU COULD

NEED

THOSE ITEMS TOMORROW!

