



NOTE 1. STOP LIGHT GOES ON WHEN BRAKES ARE APPLIED

NOTE 2. DIMMER SWITCH OPERATES HI AND LO BEAM OF HEADLIGHTS WHEN IN SERVICE DRIVE (D).

NOTE 3. TAIL LIGHT GOES ON

NOTE 4. TO PLACE SELECTOR LEVER IN BLACKOUT DRIVE (A), STOP LIGHT (C), OR SERVICE DRIVE (D) UNLOCK LEVER (E) MUST BE LIFTED TO UNLOCK POSITION. NO LIGHTS OPERATE WHEN SELECTOR LEVER IS IN OFF POSITION.

NOTE 5. INSTRUMENT PANEL LIGHTS ARE BRIGHT IN PANEL BRT (H) POSITION. THE AUXILIARY LEVER CAN BE OPERATED AT ANYTIME IN ANY POSITION.

Foldout illustration No 2. Operation of light switch.