

PS

THE
PREVENTIVE
MAINTENANCE
MONTHLY

AUGUST 1951 ★ ★ ★ VOLUME 1 NUMBER 3



WILL E. RYAN



ERWIN, THE INVENTOR

This is the story of Erwin,
the guy who found the coolest things.
Inventing was Erwin's only real passion
..... for love, his life.

What time he didn't spend inventing, Erwin spent reading about inventors great and small—and he thought Benjamin Franklin the greatest of them all.

The casual dog-eat-dog world where he now invented nothing revolutionary, or even very useful, but that is not important. As long as Erwin could be inventing something, he was happy.

Then Erwin got inducted into the Army and advanced very rapidly to private. Erwin's big score landed his way into an M1A tank, which gladdened his heart, for Erwin—because of a previous lesson a tank is an inventor's paradise.

Every matter's out of us who went through basic training with one Erwin, one M1A, one olive drab or tan, and maybe even a washing machine, was shipped to just one landing helicopter just about at the same place.

That is with Erwin. That M1A was Erwin's plane. His heart sang. Erwin was sure he could exchange that tank and drive Chindooz in place or way where they would have done better.

Which, unlike other tanks, you have that, he succeeded to do.

You would find Erwin out in the tropics some way later of day or night, slipping to the happy sleep of his tank . . . fighting the sleep with gears from his washing tank.

It was time at all his M1A tank settings, a flight of eggs, coffee, hamper, several more machine-guns, several tanks, two more escape-hatches, involving Erwin in neighboring Indonesia in need of egg and coconut.

Then the good life in Erwin's M1A was cut short by an unfortunate accident a few weeks ago in the hills up near Paothen.

In the late dusk of Friday evening, Erwin's tank was tipped off the landscape by a single round of air, which found a spot of narrow plate that was softened up where Erwin had washed things, but too long his beloved coffee hamper.

SCARY! Why scary? If it hadn't been for this one small misadventure that spoiled all his other good and table wares, Erwin might have gone on to great things.

But alas, Erwin has just given up.

LIFE OF AN AUTOMOTIVE PARTS MAN

I work behind the counter
In an otherwise sleepy store,
Sometimes I'm called a "grease"
Sometimes I'm called a tough crew.



I think I'm an mechanic
But when a job gets slick
The mechanic comes in with me
To make the darn thing tick.



I'm supposed to know the numbers
Of bolts and nuts and gears,
For every car that was ever made
In more than forty years.



I'm an engineer, a scientist
And what are, Oh my Lord,
I'm supposed to be an Edison
Combined with Henry Ford.



But life would be a pleasure
And I'd give them out to eat
If the mechanics would just tell me
The Hook—Nuts and Tnut.

Harold L. Cilman
Assistant Camp Editor

JUNE 1955 IN THIS I S S U E

ARTICLES

428 Uncle Elmer Are Your headlights On the Beam	94
A Group to Watch on the Hill	94
How to Use the 1945 No Littering Decree, There Full Strength from Washington	111
Bank Drafting	119

ESSAYS

Henry Alden's Comment Must It Be This or That?	100
Sam Green Invents Between the Lines	116
Military Packaging and the 40's	42

EDITORIALS

Editorial	78
Commentary	91
Current Note	98
Contributions	113
Special Last Minute	121
Age, Half-Page	128

SERVICES

Reader Opinion Survey	131
-----------------------	-----

F. I. MAGAZINE is published monthly in the interest of Progressive thinking among far-sighted world distributors in all organizations as part of the **INTERNATIONAL MANAGEMENT PROGRAM**.

F. I. Magazine is glad to get your ideas on articles and illustrations, and is glad to answer your questions. Just write to:

Editor, **F. I. Magazine**
American Printing Company, Maryland

Subscription: Six issues a year \$4.50. Single issues 80¢. Send orders to: American Printing Company, 3001 North Avenue, Baltimore, Md. 21218. Enter my subscription for _____ months, for \$____. Bill me () or Bill my company () at _____, _____, _____, _____, Md. 21218. Name change. My subscription should expire _____, 195____. Payment of subscription orders by **U.S. Money Order**.

HAS YOUR AGE GOT

CRACKED ELBOWS



**LITTLE DROPS OF WATER AROUND THE EDGES WARE
HOW TO LOOK FOR TROUBLE INSIDE THE CASING.**

Maybe yours is and maybe it isn't but don't wiggle on a hole in your 4 1/2" cylinder head in the water-meter elbow, it could be done.

As you well know, the water-meter gasket houses the stemcase for your casing gasket, its most vital elemental within its casing, its snugly into the hole in the elbow. They're made for each other, but some of these holes are not deep enough.

What happens, of course, is that the stemcase washer sticks out of the too small hole—and you don't get a nice finish when you bolt the elbow onto the cylinder head, so there's your hole, gasket or no gasket.

If this hole is your only trouble, all you do is to have about 1/2" (or enough to make the washer flush with the elbow) ground off all the way around the bottom

end of the stemcase washer (see Fig.). Then you put things back where they belong—you may need a new gasket (GASKET-HOUSE Gasket, water meter elbow)—and you're all set.

It could be, though, that you'll find a cracked or slotted elbow when you make that check for leakage. The replacement elbow you get (PERMA-CAST Elbow, water meter) may have a hole deep enough to make a good fit. That'll save yourself a lot of trouble if you'll check it before testing around with grinding down the stemcase washer. But if the hole in the new elbow isn't large enough to hold this washer flush, you know what to do.

The cracked elbow and gasket resulting from all these too small holes in the casing, can be returned to old manufacturer for credit.

Combat Maintenance Stories

STORIES FROM THE YEARS OF
COMBAT FROM 1942-1945
AND 1950-1953

BOULDER AND MURDER

By John Sandgar

I learned about boulders in the high ground up around Tropic one evening last July when my commander and another M41 crew were trying to break out of a dead-end by going counter-sentry. We must have got caught and got ourselves hung up between two boulders. That's a truck accident just like that.

Only one truck concerned.

Nothing at all happened in the other tank, but we had him stopped. Couldn't move back or forward, and he'd used up all his ammo, so we worked for the guys in the last get-out and blow up the tank.

I know this isn't maintenance, but it sure is a lesson for me and those other fellows about good driving in rough country.

For as I know neither of those tanks ever was recovered.

MATCH MAKING
Col. Sam Schwartz

It was the very afternoon when our M4A3 went places we going in there as snow-camp up around Changju. I was making games to number two tank ... the longest spot in the diamond formation ... when all of a sudden number one recovered a mine. Must have been double up because it blew his right track apart like it was water! Got because wasn't it happened we took three from that mine-camp and that our right track was. That was when we tried to get out and couldn't break the escape track line. But—yes, talk about events. No one wishing that they could have those tracks at the ready. Nothing left but to get the hell out the main entrance before we got finished off now.

I came out trying to beam up all these handiwork without taking a breath, but it didn't help none. I took one of them in the right leg, and I feel plenty lucky to be kept from getting so you like this.

Mine-camp? Dammit, if I get it to

get the 4 minutes of those things, you bet I'll see that tank is ready to fire out of.

DRIFT FUEL
Sgt. C. R. Prester

I was commanding an M4A3 in that action down north of Hsinchiang in the Meuse from where most of what we did was to break our track columns, see to and machine gun positions, and fill holes.

This is, when they get worse, looking up our defenses.

Continued ...

We got ourselves a couple of those fuel filters that go into the system and we hooked 'em up to both our tanks. Never had any of that kind of trouble after that, even though we put 3000 miles on 'em, and still had 'em at the end of that party for a while before the parade.

But even then we figured if those gas filters had been a little more useful it would have saved us a lot of trouble in the first place.

I pointed out to my crew at the time



what could happen if we'd been fished up like that in a real sticky spot. [The 120th's commander swallows fast.]

BOUY LEADER

Apr. 17/6. At Pencilly

You talk about Joe Dope's assessment, now it's the truth. You never know when you're likely to see him when you don't have your hair wild about. And do I know it.

One day last there we're having our first light tank up a three-mile slope trying with all our might to come into infantry marching toward heaven. It's a steep we're getting down it with all spouting out the little things on the head drive, and all the time small things and it's an making average music on the tank.

That is when we get this Joe Dope up position.

Headed with on the down of moment, due with . . . separate here have to be launched back with a hammer to get the number out . . . and delicate sublogged

up to was but sometimes trying to cheat the benefit.

James get my hands on the great off leader that had that tank before we get in and I'll be in the end next.

LEARN FROM THE GREAT

Ph. Norman Brown

I know you will you want to hear our experiences with maintenance under fire, but I've seen your readers aren't going to complain if you heard them a few hours an operation over in a while if it meant their getting out with a whole skin.

Myself gave the new tank make their first real field testing under fire and we learned a lot of things about them, you might say, from the enemy himself. Like we caught the guide trying to climb up and drop grenades in the engine hatch.

The order was come out to her and look back over, but the big tank, we learned was to try and think in advance of all that kind of thing before the enemy gets there first.



WHAT'S YOUR DREAM HOME?

Did you give a look into Southern Bell's P.O. Budget and take up the whole program? Did you give up a new look-changing world with only a single line? Well, that's your chance to make that look coming. We give off with a free personal consultation in 11 Southern Bell's offices, P.O. Budgets, American Trading Center, 24.



HOLD a procedure for adjusting the headlights of any and all transport vehicles. It's guaranteed to aim the hot spot of the headlight beam exactly into the ground 100 feet ahead—and guaranteed that hot spot is 500 feet in clear when the glare is out of everybody's eyes. (This adjustment is S.O.P. The authority is GM 1982 107 104 [see 104].)

Before you do any adjusting, though, here's a heads-up: Make sure your vehicle's gas tank is full, its fuel level, if possible, is just low enough, you'll be wasting your time. You'll get the adjustment perfect, all right, and the hot spot will hit the dirt at 500 feet on the nose, but the minute you start down that highway road with cargo, the adjustment'll be off, plenty. You know why—when your vehicle's loaded, the back end gets weighted down. Hey, don't end this up at the same time, and the headlight beam sits up with it. Then the hot spot's glaring at the whites of their eyes instead of at the ground. So you check off the following adjustment when you're carrying a load (in the truck):

(1) Find yourself some level ground. If there's pavement in the vicinity, fix some place on the level stretch, you'll need a vertical surface—wall or fence, anything that's straight up and down. Now, with a tape or yardstick, mark a line at right angles to the wall and bring it out 25 feet from the wall. Then at the 25-foot mark, draw a straight line parallel to the wall. Your work at an should look to resemble "T".

(2) Drive your vehicle up to the "T" between the headlight's centerline and the 25-foot line and aim directly over the straight line atop the "T". Measure the distance from the center of the headlight to the ground. Mark off that same distance on the wall, from the ground up, and draw a horizontal line through that point, directly in front of the vehicle. Call that line A.

(3) Now line B is the same distance from the ground at the center of the headlight. Measure off 1/3 of that distance and draw a second line just below line A and parallel to it. Call the second line B.



(4) You've ready now to draw two vertical lines through the two horizontal lines—the vertical lines must be directly in *depth* of each headlight. That can be done accurately by dropping a plumb line (or a heavy nut on the end of a piece of string) from the center of the headlight to the ground.

(5) Measure the distance, on the ground, from the point where the plumb line landed to the 24-foot line of the "T" formation. Then mark off that same distance on the wall and draw a vertical line straight up. Do it for each headlight. Call these lines B and C, respectively.

(6) Turn on the headlights now, and feel high beams with your intense vision. (You needn't make any adjustment on low beams.) Cover one headlight while you're aiming the other. Aim the headlight at the low spot of the beam-pattern at the intersecting horizontal and vertical

lines A and B, or A and C—depending on which headlight you're adjusting.

(7) After you've adjusted each headlight separately, check 'em together just to make sure they point up and down on line B.

And that's it. If this adjustment were made on all heavy vehicles, there wouldn't be any more of that "blindness" that kills too many with cars. You know what you're driving in the dark and your glare comes from the opposite direction in a flash of light and glory, you don't see *nothing* for the next few minutes. Nothing except maybe a bright red baseball floating around in your own private blackout. And that dose period of blindness is enough to send you careening off the road into the valley, or into some body's tailgate up ahead. Okay, okay—so you'd better aim 'em.

The price is: Are your headlights in-tune or gummy?

A COUPLE MORE ON THE M34



ENGINE BREATHES EASY

Your M34, like all Mopar cars, has a system of engine breather lines which let inside and outside air be shut off by a loading knob. You can shut them off (see Fig. 1). When the valves controlling this air are in good order and set as they should be, everything



Fig. 1 — By the time you close your first mouse, know the knob and what it does.

is fine because that they'll close only when the loading knob is pulled. The dash won't close at any other time. Unless you want trouble.

Closing the valves built up your lungs of pressure in your engine and crankcase. This is pressure you've got to have when loading, to keep the water out. Nothing's going to split its seams while you're in the water since the system's designed on the theory that any loading movement is

linked to very short stretches of time. Enough pressure to keep the breather dry and you're moving.

But—take the same amount of pressure being built up on dry land and you've got an 8000 loading for the duration.

One of these valves is on the intake line at the air cleaner, another on the crankcase breather, and a third on the manifold cabinet (see Fig. 2). Only one or all three of them getting shut off can do damage, anywhere from expiring your oil all over the place to completely wrecking out the engine. With no ventilation in the crankcase, you get sludge and corrosion, and unless all the gas and water vapor



Fig. 2 — The dash for mouse goes to the knob that shut the valves for loading.

get carried off to sea as they burn, they're going to turn into an acid which can eat the finish on all the metal sur-

From there that lead is gone how long are the bearings, and the cylinder walls, and the piston, and the thin and thin going to last? They don't.

So you can see (Fig. 2), the wires leading from the standard valves to the dash control-leads are attached to the valve lever with a set screw. The valve lever is in a correct position when it's pushed up against the stop on the connector—and the attached wire should not be dragging it down even the slightest. It doesn't take a half an' more down on that lever to close the valve. You can see how slight a force is needed (Fig. 11 . . .) with the lever in this position the valve is tightly closed.

Has checked them yesterday, but how about right now before you put the rest of your points in that cable? Do you know how many bumps and jabs it takes to hammer them on wires—up where nobody finger may have been so wise enough to pull down the lever and close the valve? Check 'em, man, before you operate.



Fig. 2—Is you get worry about it, it may beat the one made by hand sometimes.

SPARK-PLUG CABLES

How many spark plug cables has your (M) used lately? One more, is one too

many. Covered threads in broken one means screw up the whole cable assembly, and the threads get crossed and the connector get stripped because someone in the crowd's got allowed to touch head-plate (Fig. 3). Someone gets careless with you little connector and it necessitates the replacement of a costly assembly. They just don't come separately.

The connector in the top of that cable is porcelain. Porcelain, like china. You may hear someone wouldn't last for one bang of a cylinder head. Porcelain do the connector.

The cable itself isn't very flexible—it gets worse in cold weather—and the



bumping cable certainly somebody is who'd break that hard-top operation.

plug you've gotta screw it into the eye to see how tight to get it. You know, but what you aren't remembering until too late is about that porcelain.

Another thing is that the threads are getting crossed screwing the nut into the plug. Maybe, since the cable isn't real flexible, and the porcelain kinda tough mean for your typical work, you should make the nut finger-tight before using the wrench. You can feel better with your fingers anyway.

CONNIE ROOD'S

"SHORT 'N' SWEET DEPT"



BULLETIN

Don't let 'em get away from you!
What's happening and how and why, better keep an eye on these new 300 2 1/2-ton trucks now.

If they start to jump out of range, it probably means bearings out of adjustment. But you can do for now to spot the trouble and stay out of all-out drive when available.

Connie

DRAC AXLE END-PLAY

When automatic-disconnect front-end shaft and U-bolts assemble during the 1955 model check, they sometimes showed the axle shaft because it seems to have too much end play. This isn't a good idea. Slack and play can't be decreased after the shaft's been removed from the housing, they often showed good axle shafts.

From GM's Service Representative H. A. Wagon comes the following advice:

On the split-type axle, end play is all right before the shaft is in the housing with shims under the thrust washers on the differential end of each shaft. The shafts are held in place temporarily by a screw which pulls the driving flange up against a shoulder on the screw ball of each shaft. When the screw's taken out, there's naturally a bit of end play as you move the axle shaft back and forth inside the housing.

Always check the amount of end play in the split-type axle before removing the shaft from the housing; that way you can take out excess play by adding extra shims when you reassemble the unit.

On the beam-type axle, end play is controlled by tension thrust rings on each side of the universal joint. The washers work against the ground surfaces of the joint. To decrease the amount of end play in the beam-type axle, check the condition of the washers when disassembling the knuckle and replace the washers if they're worn.

In other types of axle, you're bound to have a certain amount of backlash from worn balls or pinions; but you can correct it easily enough by using smaller balls. In the Bendix White U-joint, since the screw ball doesn't get much wear, it doesn't come in contact.

ONE CARBURETOR (OR TWO)

I've got the answer to why a lot of people can't get the Zenith carburetor adjusted for a proper engine idle on the 175 cc GBC's.

It starts with leaving all the holes that support the air stream on this job (and why anyone should leave all the holes is beyond me). Thus, in order to support the non-reinforced air stream, they tighten the already tight screws on the carburetor just about every nut. This causes the chokes the two screws on the rim of the carburetor. (see Fig.)

If the carburetor is white metal, cleaning down these screws around the bowl here at the throttle body to wrap right along the gasket. The wrapping makes just enough of an opening to let air leak into the carburetor at this point.

If you can adjust the carburetor to give you a good idle with this air leak present, you're a better man than I am.



WHY A FAN SHOULD

If you're ever wondered whether the fan should and should on your engine back anything but get to the rear, you'll be interested to know they're a good part of what keeps your engine from starting up a blaze. You can never have enough fan to make you—better keep your mind on. With the fan operating, the stream of



FIGURE 1 FAN SHROUD

airflow and together as a part of wind tunnel which sends a small percentage through every square inch of radiator core (Fig. 2) and puts a quick stall on the water inside. This controlled-flow arrangement keeps air from getting a free ride by breaking around instead of through the radiator (Fig. 3). In addition, it keeps hot air from recirculating through the engine compartment.

Another thing—the fan head is also part of this "wind tunnel". It helps join the cool air back over the engine and if you think it's good to open it when the engine overheats, you're wrong. You'll just have one other lesson that flows so good. But, if you keep your stream on and your head fastened down, it'll be easier to the engine department.



FIGURE 2 AIRFLOW THROUGH

NEW TRICK FOR SCREW-JET VALVE-CRACKUP

If you're a big, heavy boy and you're driving a factory test Ford, factory boys right out and take a look at the screw-jet valve (on the side of the engine). It's built anywhere between the 1939's and 1940's (probably), you're got a job to do. The manufacturer changed the design of the screw jet (the reference screw jet) in '40. What they did was separate the screw from the cylinder with (see Fig. 1), using the same screw as before. After manufacturing this type for about five months (including the screw maker's plant already), it was found that it just got too much pressure on the screw, they're likely to crack or break the screw. That's let water leak into the cylinder.

What you've got to do is remove the two old screws (Ford's Part No. 17-11201-1 and 17-11202-1) and replace them with new shoulder-type studs as shown in Fig. 2. You can get these studs through regular channels (Ford's part, 17-11201-1, and your good 1939 screw). Before installing, slip the new stud back up to the shoulder (see Fig. 2) so the shoulder will fit in they'll hold tight.

This does it - the studs' shoulders will stop you from cracking the screw.



CONYOT CRACK-UP

Today it ain't just kids to get cracked. Today I saw what went out a door and driving Conyot, some slipping back with some interesting Conyot news. FORDS the just one they're cracked, but look inside of a few seconds.

"What happens?" "What's the cause?" One of them, a couple all at them? How can you say? Why is the speed even faster?



the visibility gear, or someone paid an attention to a more dignified, or maybe didn't give it back, or there was too little distance between vehicles. Any one or all of these things.

I only know that each driver in a company is carrying a couple of loads—the load in his buggy and the bigger one on his shoulders. I worry about the guy in front and the guy behind, and worry about everyone else in the company. Because it takes only one mistake to travel along the string and wreck the operation.

You know, some guys are walk by their partners with the loudest tone: "WE HAVE THE WORLD'S BEST EQUIPMENT!" Take care of it, with a string of their big shoulders that says, "—Yeah, yeah, well it is to me again." But not me. I walk by one stiff and hear him say, "The thing plugged with a stick, and light up inside, and straighten my back. It's proved itself good."

Just as these things are. You will please excuse me while I wait in the lobby for a good cup. I love that equipment.

OIL-MAIL CLEAR FOR HEAVY-TRUCK AXLES

THE 3002 (10) provides an oil seal protector for Daimler, Caterpillar, Dresser, White, Mack, and White-Luffkin trucks. The run oil seals over the outer ends of

the front axle bearings and getting fixed up when the drive shafts (Timken series F-100) are removed and reinstalled.

The protector is a snap ring (Cham Stock No. 100-104-114). It has a tapered section (Fig. 1) which guides the drive shaft as you don't slide the oil seal.



4MM BLADE CLEARANCE

Some M.M.'s get out with their big blades cutting too close to the generator. If you haven't already taken care of the wear—maybe it isn't enough to bother you—get yourself something like a four-ounce handle and spring the blades away from the generator shaft a little. Later models are already coming through with sufficient clearance between the fan blades and generator shaft, but maybe you don't have one.



JOE DOPE

HOW TO WASH A G.I. TRUCK

1 WASH THE TRUCK
WITH SOAP AND WATER.
USE A BRUSH TO CLEAN
THE SPOTS. WASH THE
WHEELS AND TIRE WITH
SOAP AND WATER.
WASH THE TRUCK
WITH SOAP AND WATER.
WASH THE TRUCK
WITH SOAP AND WATER.
WASH THE TRUCK
WITH SOAP AND WATER.



REPRODUCED FROM THE ORIGINAL DRAWING BY
JOE DOPE FOR THE U.S. ARMY





NUMBER ONE

BE THE FIRST TO REVEAL THE SECRETS OF THE...
...OF THE...
...OF THE...





NOW YOU ARE
READY TO
WASH THE VEHICLE.

I GOT A
LITTLE SOAP
HERE.

THE
MACHINE
IS
READY.



THE
MACHINE
IS
READY.



HOW ABOUT A WORD ABOUT STEAM
IT STINKS!!!



BUT
WE'VE
GOT
TO
KEEP
THE
MACHINE
RUNNING.

AAA... THE NEW GARBAGE
MACHINE ISN'T WORKING!
THEY SAID IT WAS THE BEST
ONE... ALL THE OTHERS WERE
BROKEN... THIS ONE IS
THE ONLY ONE LEFT.



ACTUALLY THE BEST ONE
WAS THE ONE THAT WAS
BROKEN... THE ONE THAT
CAME FROM THE
CITY...





"PURE
LAW,
PERRY!"

"WELL,
WELL!"

"NO, I'LL BE HONKING! THE
MACHINE'S THE PROOF OF
YOUR OWN COY AND
WELL, I'LL BE HONKING IN
YOUR OWN COURT!"



"WELL, WELL, WELL!
WELL, WELL, WELL!"

"WELL, I'LL BE HONKING!
WELL, I'LL BE HONKING!
WELL, I'LL BE HONKING!"



"WELL, I'LL BE HONKING!
WELL, I'LL BE HONKING!
WELL, I'LL BE HONKING!"

HONK



"WELL, WELL!"

"WELL, I'LL BE HONKING!
WELL, I'LL BE HONKING!
WELL, I'LL BE HONKING!"

Joe's

Dope Sheet



WE HAVE THE WORLD'S BEST EQUIPMENT



Joe Dope isn't one to
walk back
For the space he left out of
the rack.
Now each turn of his axle
Turns up no more taxes
That half-a-year's pay
they'll subtract.

EQUIPMENT... *Take care of it*

HOW TO USE AN SNL



To your satisfaction as well as our—
 designed and your SNL needs in
 your own hand. Now all you have
 to do is order one... through
 channels. And when you're not
 sure how, ordering through chan-
 nels can often mean a big fat
 headache.

To keep you from hitting the
 APC handle, here's the story on how
 to avoid registration headaches.

READING FROM



Let's start with Section II of your
 O&B handle. It's the book that tells
 you the correct SNL to use. Section
 II of O&B-1 says it is 249, 0-244.

Book of Reference Special Columns are
 right-hand side. If it has a zero in
 it, the steel check with book of
 Specs—then fill out the lower slip.

LEFT TO RIGHT — HERE'S HOW!

A page from a tax form, likely Form 1041, showing various sections for income and deductions. A red box highlights a line item in the 'Other income' section.

2 You know that ORO's is used to use for Major and Field Memoranda. Also, you know that you'll find your assets covered in the pages of the Civil 2.

The cover of a binder or folder, labeled 'POLICE-34M'. It features a title and some text, possibly indicating it's a manual or a set of forms.

3 Now reach it off the shelf — cover your books — open it to the "Index" given in page 20 — read down the alphabetical column to number.

A page from a tax form, likely Form 1041, showing a table with columns for 'Description', 'Quantity', and 'Value'. A red box highlights a specific section of the table.

5 Get the check number, date issued, manufacturer and quantity of the substance listed Column 3. Then — then you needn't look in the book.

A page from a tax form, likely Form 1041, showing a table with columns for 'Description', 'Quantity', and 'Value'. A red box highlights a specific section of the table.

6 The checkers you make from this table you'll get parts. This is how to prepare from this table . . . and things you get you'll be notified.

IBM FORM 6-244

INTRODUCTION AND INDEX

FORM 6-244		DATE	TIME	STATUS	ACTION
1.	...				
2.	...				
3.	...				
4.	...				
5.	...				
6.	...				
7.	...				
8.	...				
9.	...				
10.	...				

There's not one when you try it, that your back will improve in getting what you need when you need it, if you'll whip up your orders from the right ingredients.

CONTRIBUTIONS

WHAT WE
READ FROM
THE BOYS
IN THE FIELD



RAYCHET RESOLVE

Dear Editor,

I know how important it is to have a weather that's working, and how it becomes another piece of luck when it's not working. Here's a fix on the weather CRK file, starting that puzzle with the numbers it's based on.

By taking the wheel apart, I found out where my trouble was. The great job that comes up to the hub would stop the hub from going from right to left. By cutting a piece of the brass my Chevrolet was and placing it across the piece, gas and water the hub can (Fig. 1), I got the wheel to work good as new.

Sgt. Henry B. Pines
MFA, Infantry

[Ed. Note—That's pretty far the particular number you've got, Singh. There are some other numbers listed under the name Paul Smith No. 17 (1-1-1951) which don't seem to help any.]



KLEINBERG SHAK

Dear Editor,

Both Tim Hill and Tim Harlow—by the (7-1-44-194) CRK—tell you to ensure them to add torque, when adjusting the steering-knowledge assembly on a split-type axle. But what if you have no axle left and still need more torque?

Here's what I'm doing. When the bearings are still in good shape, I take a piece of 1/2-inch stock and cut a 1/4" hole in it. I then insert it in the shoulder of the transverse, put them ends of each cone and then add more.

W/Sp. E. N. Bennett

[Ed. Note—Covering these ideas will take up the knowledge-bearing piece and keep the air bearings from coming loose. But when you get in the street, make sure the CP gear inside the ball bearing has plenty of room to rotate—otherwise the axle is jammed. Please send us the bearing setup work file, too.]

STOP AUBURN RUP

Dear Editor,

Here's a fix for all those loose rear-view mirrors.

The ball and socket on the rear-view mirror gets loose so much that the adjusting screw doesn't tighten enough to hold

the mirror mechanism. Before the contact has fully set, an insert axial spring (see Fig. 5). The tension of the spring will hold the mirror in position.

To prevent rust and sweating out of the ball socket on good assemblies, apply a drop of oil to the socket occasionally.

Harry Brown

Chickamauga Camp Technician



Fig. 1—Flap stopped by adding a wedge.

NEW DANGER FROM OLD

Dear Editor,

I've found it easy to fix jerry brightlight dimmers without a test, when there's "blue color" of dim, dim, mad, and general overexposure—causing the dimmer tubes to cease functioning properly.

Ordinarily, the indicator light is all that is at the salvage job, and built through "Pilot" for a new one.

I've found that although it's a "cheap" job (which usually means that the "indicator" lamp burns off), this one will stand opening up and working several times before the longest lamp will do. If you start's indicator is burned, you'll usually find that a little oil will do, but liquid will get inside, when they will be done to the contact, just and make sure.

A piece of tin-plate (16 gals) and some dry-cleaning solvent will make the contact almost as good as new.

The same goes for the starter switch on the jeep, though here it's vital to see it fit and keep the contacts as good and parallel as possible.

Ag. Edwin G. Nelson

SPARK PLUG MIND

Dear Editor,

It may have been one of those rare occasions of modern production that one of our AC's (while spark plugs had a direct of metal left in the barrel after all the milling and assembly operations, so it may be happening right along.

In either case, such a production still means a distorted view to somebody's firing order... and maybe, the with it, they hear down trying to find out why number six in an M-24 was firing and firing.

That's the thing because it was only by ground on a hair and about 1/8" long... but, the right, due to most up with the spring barrel and ground it, too. No. 11

Raymond E. Smith, OGT

Camp Technician, Va.

Chickamauga Camp Technician



ON FIRM TOOL

Dear Editor:

On films on the 16-mm. Model L-171 International Spring Machine were giving us considerable trouble, during the following up of the 5000-5000 run in the last half of the film (Fig. 4 below), the popped Sgt. J. D. Williams, 44th Army Dental Truck Company, with a tool he made out of this tool-to-get-out.

The Sgt. got himself a piece of pipe 17" long and 1/2" in diameter. About 2" from one end he drilled a 1/4" hole through it. He then got himself a 1/4" bar of steel, about 2" long, and drove it through the hole in the handle. On the other end of the pipe he welded a 1/4" ball-bearing socket (see photo) to hold a gauge, (Fig. 5) that worked like this: The Sgt. first removed the top spring cover and cartridge. He then slid the socket and ball-bearing pipe down over the center take until it got on the rest at the bottom—after it struck with the rest and the trouble was cured.

MR. H. E. DRAY
Automotive Industries
Redwood Wood, Mo.



FIG. 4



There are several other ways to do the same job without open-end wrench, or with the open-end (conventional) wrench which sets loosely.

DISTRIBUTORS IN RUSH

Dear Editor:

After reading a contribution by Ed John P. Thomas to ARMY MOTOR (Apr. '74) on installing Chevrolet and GMC distributors, I'd like to make this suggestion. If you're working alone, use a wrench which is a 1/4" open-end wrench on the flat bar of the roller linkage just above the spring. You can then operate the spring while installing the distributor. Remember the clearance that must be maintained at the upper and lower ends of the distributor housing before tightening the clamp bolts.

ROY E. SMITH
Kilbuck Springs



NO SITTING DUCKS, THESE

How Brown Two Mores On
Keeping Your Ducks In Line



THE Ducks of the Allied Amphibious Task Co. waddled from the jet of Europe to the other in World War II through a series of aviation tests (4-Eng to coverage of the Blue, the Blue, the Liberator, the Blaine and what have you).

Though they weren't ready to roll at by the time the landing was over, they were still alive and kicking. Here's some of the maintenance tricks used by the men of the Allied to bring them through.

FUELING THE

Changing fuel filters on the duck with the dry-connection system, the mechanics — Sgt. Tom W. Hanson, Duck and Truck Mechanic, learned from experience a much better way of doing this job than other men do.

Undocking the shaft of the engine, as recommended in the book, is no hard job at all. The hole that connects the drive shaft with Hanson does in one look the drive shaft of the air compressor on the forward end of the radiator (Fig. 1). There's only one way to get it (with a 12" wrench) being there. Then just slide the shaft back until white mark (5000) is lined and slip the fuel filter around the shaft.

How to get the fuel filter on the other side of the radiator where it belongs, requires a little thought. The hole in the case that the air compressor shaft goes through, drops it around the pulleys, and just a little up the shaft, and you're done.

You cut the job down to about 1 minute.

GENERATOR PROBLEMS

When the mechanic ain't around' and a duck shows that the generator ain't generating, Hanson has learned to look for one little thing on his ducks. See



Fig. 1 — After you've loosened the filter and slid back the shaft, all's left is to slip the new fuel filter right into place.

water. In steps, scrape into the generator and provide the little springs that hold the brushes to the commutator. These will tend to press the brushes against the commutator.

Now, instead of pulling out the brushes and replacing the generator top, Houser has taught himself a little trick that gets his generator back in service in the best of all ways. All he does is flip open the commutator cover board, reach in the finger, and slide the little wires or levers that work off the coil springs to press the brushes down (Fig. 1). This releases the tension on the springs and gets the generator working instantly.

As you can imagine, this is no more all for convenience in the generator, but as you can readily imagine, there are times and places when you've got to get going in a hurry. As far as the generator is concerned, this is the way to do it.

In the problem of generating off electrical appliances (including the generator) from salt water, landline, and (again somewhat more) air or water, the first step is to get your hands on a copy of **THE OGD 541, "Protection of Electrical Appliances On Submersible Vehicles Against Corrosion and Rust"** OGD 541, 402.

Getting back to the brush springs, the bulletin tells how the springs can be protected against corrosion. But you've got to go way over corrosion-proofing compound (CP) crystal points. It slipped on the brush, may cause the brushes to stick in the holders and the brush levers or pins may bend. Another thing, glycerol is a good insulator and you don't want it to lose conducting into non-conductors.

To corrosion-proof the brush springs, do as follows: With the brush-pins assembly out, clean off all corrosion and rust (new springs should also be cleaned). Dip (brush only) a light coat of glycerol (oil makes them about 50% thick) on the brush springs, pins, or levers, and on the

visible surface of the brush holders. [Keep part off the inside of the brush holder where the brush sits.] The stuff dries in about two days.

That ought to do the trick as far as the brush springs are concerned—but remember that Houser's trick of lifting the little wires to lay them, it may get you out of hot water in a hurry some day.

To do a complete and all-over corrosion-proofing job on the electrical system, get a hold of **THE OGD 143**.

UPBEAT ON ME ...

Lots of little things creep up to plague the crew and decks of the ship. The lights, the batteries. The sealed beam units in the headlight get hot, when lit. When the deck splashes into the water, the cold water soaks them and they crack. What's the answer? The answer, with sealed beams, is to remember that they'll crack if run into cold water while they're hot, so try not to use them for a couple of minutes before dunking your deck.

The little spring connections in the tail lights also get it hot when salt water hits them (Fig. 2). In the third quantity, make the electrical connection by spreading a little ball of solder in place of the spring.



Fig. 2 — A quick fix of the levers is usually all that's needed to bump up corrosion and start it generating again.



Fig. 1 — When the salt water has done its dirty work here, a couple drops of salt water will take the place of the spring.

The boat goes, too. It's no trick at all for salt water to float in. Whenever they run counter air, the #1 ball replaces the old leaves with air leaves. They take their air up to the air-compressor system.

Like everybody else who had trouble with losing the leading cap (Fig. 4) of the propeller-vent leading assembly, the #1 ball welded a little chain on the top so that when it did drop off, it won't be lost forever. Cap's on the boat again.

The little pulleys that the rubber-vent ball runs through (Fig. 5) are made of some sort of fiber composition. Because the rubber should be running enough to



Fig. 4 — When you hear or see other people with questions about these things being welded chains here to save losing the leading cap.



Fig. 5 — Keeping these composition pulleys well oiled is the secret of the fiberglass rubber-vent's you've heard talked about.

prevent the fiber's stretch, the #1 ball found it wise to keep the fiber pulleys well oiled on their pins. Otherwise, corrosion causes the pulleys to stick, the rubber wear through, and next thing you know, spouting your deck in the steering a pair of dead horses.

The retractable guide located on the front of the hull (Fig. 6) sits up there waiting for trouble. When there's not a ton, whoever comes out to see a matted deck out of the water or mud, throws a hook of a line through the cable guide and uses it to tow the deck in. This being designed for that particular job, the guide opens and you're lucky if you don't wind up



Fig. 6 — To save the guy who comes to pull you out doesn't have a retractable guide from a fishing chuddy, show him the one.

with a hole in the belt. The answer is self-repairing. Whenever it does get additional lag in such cases should be advised that the wash-water guide to use a plastic lead near the electric terminal for the purpose. Not having been the best.

Charged-rental insurance companies looked up to money for the fact in many cases, the reason is in the fact that they had done the job under the proper circumstances. As the fact goes, stopping along the various accident you will see. If a simple list of cold water is starting around under the wheel, it strikes the wheel and track puts the wheel out. However, when the car is a "wheel" and when replacement materials were arranged for the vehicle, the fact did not seem to be really broad about insurance. If the fact was not too bad, why they had with about and appeared. As Cpl. John

A. Fly of the unit says, "What the hell, if I don't have anything." Working on leaving the unit would be able.

After a couple of days, most the unit, they had left a couple of days in the middle of an embarrassing situation, the fact is that it was important to watch the various air connections of the circulation system. You too, you may find yourself in a position to have a long-term type of situation and and along with that, you need not have any "load" and and "load". Leave in material your lack's low-inflation system.

All this and his own, the case of the fact is that the fact is that the company looked the fact was. The fact of plain they want, the fact of things they do. They didn't have much choice in the fact in the things it was clearly not at all. They want.

TOW-HOOKS—GIVE IT TO 'EM STRAIGHT

You wouldn't think that putting an inexperienced or less-than-qualified operator in the driver's seat of a tow truck would be a good idea. But take a look at the tow trucks you'll find—some of them, some pulled over—discovering some of the vehicles, and you'll begin to believe maybe they do.

The whole story behind the use of tow hooks is that they were never built to take a side-wise strain. A straight pull is the only thing they're guaranteed to stand up under. A pull from the side may bend themselves, get up the mounting, and generally disrupt the neighborhood around the front bumper.

Out of the easiest ways to get a job done, one of the best is to have the tow hook pull out of the hole, just to avoid the strain. This means it's side-wise strain with the vehicle being towed.

The standard way to set up the

hook is with a spreader bar from the truck. When you get a spreader bar in your hands, but if we take you we'll have some for you, you'll have some.

You'll want to have a spreader bar, rather than using the tow hook, because tow hooks don't exert a side-wise pull, so they are built to give it a straight pull. Of course, you've got to use the spreader bar just to get a straight pull. Otherwise, it might pull out of the hole.

Remember, a straight pull and a side pull.



Hand- Tool CLINIC

AREN'T I BAWDY
ABOUT SHOWING YOU
FOUR COMMON WAYS
SAW HANDLE'S AND
HOW TO CORRECT 'EM...
GIVE IT OUT AND
FIX 'EM IT IS
YR MAT?



IF THESE THINGS
HAPPEN

THE
HANDLE



THE
HANDLE



THE
HANDLE



THE
HANDLE



...AND NEEDS
MORE TO PUT
IT.

THE BLADE'S
TOO TIGHT
OR YR
TWISTING IN
THE CUT.

REDUCE TENSION...
ALLOW JUST
ENOUGH TO
HOLD BLADE
STRAIGHT.

IT'S EITHER
NOT ENOUGH
TENSION
OR YR USE
THE WRONG
TOOTH SIDE
OR
YR BETTER
STROK
BENDING OR
TWISTING
THE BLADE
OR
YR PROBABLY
NEEDED A NEW
BLADE IN AN
OLD CUT
BEST WAY
A NEW
CUT...



14 IN



28 IN



34 IN



32 IN



FOR BETTER RESULTS
TO GET THE MOST OF
YOUR SAWING BRASS
BLADES, GET THE
CORRECT OLD BLADE
STEEL. APPROXIMATE PER
CENTS ARE:

FOR WHEELS IS TO A
SLOT IN THE BLADE. 1.5 IN
FOR WHEELS, 2.0 IN
FOR WHEELS, 2.5 IN
FOR WHEELS, 3.0 IN
FOR WHEELS, 3.5 IN
FOR WHEELS, 4.0 IN

FOR WHEELS IS TO A
SLOT IN THE BLADE. 1.5 IN
FOR WHEELS, 2.0 IN
FOR WHEELS, 2.5 IN
FOR WHEELS, 3.0 IN
FOR WHEELS, 3.5 IN
FOR WHEELS, 4.0 IN

FOR WHEELS IS TO A
SLOT IN THE BLADE. 1.5 IN
FOR WHEELS, 2.0 IN
FOR WHEELS, 2.5 IN
FOR WHEELS, 3.0 IN
FOR WHEELS, 3.5 IN
FOR WHEELS, 4.0 IN

YR PUTTING TOO MUCH
PRESSURE ON THE
BACK STROKE.
OR
YR NOT USING
ENOUGH PRESSURE.



LET
BLADE DO
MOST WORK
AND
MOVE DOWN
ON
BACK STROKE
STROKE.

REMEMBER that controlling the gas has more impact when you breathe heavily over periods of a higher volume for a longer period than it would be helpful. That cooling system was acting like it didn't know its purpose because heat in the ground. The low humidity was preventing straight moisture in the engine was increasing its own rate fairly and all... and absorption.

In what state are all about it?

You are right. By that time, you had no choice. But something should have been done long before, because the right kind of preventive breathing at the right times, an self-regulating cooling system would not get heated up enough to work any further during. That's a fact.

In the 1920s even the best operators that preventive maintenance services on some vehicles include taking a careful note of the weather for maintenance—and cleaning up the cooling system if you notice a strong sense of heat, spikes, or irregularities. The fall-back and such like vehicles, the procedure is the same. In fact, whatever liquid cooling system you have it.

And here's how you go about doing what the book says: First, you remove the radiator cap (approach with respect if it's pressurized, then insert a hydrometer, and take a sample of the coolant up to where you can see what it looks like. Now when the staff's with. But it after the engine's been warmed up to normal operating temperature and which is still running in a hot cell. Otherwise, you can get your own's show where going on.

Will, how does the book? Perry—no group possible? If you notice your part-

BASIC



for, self-maintenance. Because it's just in the engine, that's your car for driving right then and there.

To make things worse in your engine diagnostic, let's break this down into four easy steps: Cleaning, overloading, flushing and recharging.

CLEANING

The idea here is to get out as much foreign matter as possible, by the simple process of draining from below through with the cleaning compound, by use of water leading to hoses and similar gages to let the coolant circulate completely. This cover the loss of the radiator with cardboard, or anything else that will keep the hot from so long back in your the cooling fan, and use the engine and the temperature checks on the

DRAINING



normal operating range. Keep below it until you get to the boiling point. Take off the radiator cap, open all drain cocks, and drain out the whole mess. If any drain before it's clogged with grime, use a length of wire to make them open.

When the dripping stops, give me the draining compound. Under Federal trade No. 31-C-1333-516, the draining compound is packaged in a 4-pound container of draining compound and a 4 ounce container of neutralizing compound. If you mix them together, you get nothing useful—they cancel each other out. The reason is to use the cleaner first to slough grime and gunk, and then use the neutralizer to prevent harmful after-effects. Just liberating the other way round. (No reflection on your hardware, but this draining compound is a blend of caustic

and/or you'll want to avoid dripping it on things like skin, clothing, or vehicle parts.)

Back to work. When the coolant has completely drained from the system, clean all the dirt in each again. Drain out the radiator overflow tank (if your vehicle has one), and let everything cool to below 100° F.

Get each hose gasket, or thermostat, and cooling system cap(s), pour one ounce of draining compound into the radiator. Fill the rest of the way with water and replace the radiator cap.

If your vehicle does have an overflow tank, install the pressure cap over on the radiator during the draining action. Also, put a clean-dirty pan in position catch the flooding, too flow—then you can see the droppings, if you need to be being the radiator liquid up to level.

Now, run the engine at a fast idle for half an hour. That makes the cleaner work better, so get the engine temperature up to at least 200° (just use over 200°) and keep it down (use the radiator cover again—on and off as required—so keep within this heat range).

If you let the radiator boil or the engine coolant, you'll have to stop and wait until the gauge drops below 200°, remove the radiator pressure cap, pour the overflow back into the system, put the cap back on the radiator, and run the engine once more to finish your treatment run.

When time's up, shut off the engine and drain the system thoroughly, removing the radiator cap and opening the drain cocks. If everything has gone according to plan, all the junk that's coming out will run out with the draining compound.

NEUTRALIZING

Here's where you clean up after the cleaner. As we said before, this cleaner is a strong acid—a rough substance. But it hangs in the cooling system and it'll probably creep out by making its own way out. So you've got to neutralize these droplets of cleaning compound.



Now get the drain plugs again. In your immediate Ford County area, you'll find such fine gallons of cooling system capacity. In pour the water again to fill up the system. Do you see the radiator cap. Do you see the dipper, too, or the little. Use the radiator cover, if you need it to bring the engine temperature up to 180 degrees.

A radiator fan will do the work this time, but if you have a few minutes to spare, it's no harm to circulate the new coolant a wee longer. Once again stop the engine, remove the radiator cap, open all drain cocks, and let the overflow plug leak.

FLUSHING

Since every trace of the cleaning compound or the neutralizing compound must be got out of the system, this step is an important part of the proceedings. Repeat exactly what you did with the neutralizer, only fill her up with plain water this time. A radiator fan, or one less than 180° and not more than 200°

followed by the fourth draining.

You may find it a good idea to double flush with the water. There's little doubt it takes the little draining or two out of your water.

And to really complete the flushing operation, it's smart to clean out the valves in the radiator cap. Spray a stream of water if you can get hot water, goodly through the holes in the valve cap—move the pressure valve up and down, with a light piece of wood in a pinch, at the same time.



Clean out the overflow pipe while you're at it. Flush the overflow tank and connecting tube with water. And use your compressed air gun, blowing from the rear of the radiator, to clear out dirt, scale, and insects included in the air passages of the fan. You can do this with a stream of water, too, but don't use steam. And whether you use an air hose or a water hose, remember that too much pressure will damage the radiator. Keep the hose at a safe distance.

Before having the flushing operation on a second occasion. One way not to flush a cooling system is to shove a hose in the radiator with the engine running and the drain plugs open. That power does clean the displacement valve, stopping circulation and preventing the water from churning through the engine. An

other important thing. Fill an overboard engine with cold water. You can easily check this matter with a simple device. Let the engine run as before for 15 minutes, then add cold water. You shouldn't let your engine go above this heat during that clearing business, anyway.

WATERING

For the first time, shut the drain cocks. Then proceed to fill your radiator with whatever the climate calls for. If ice equipment, inhibitor, corrosion, you fill the cooling system almost full with clean water, first. Then add the inhibitor in the familiar proportion — one container for each four gallons of gross capacity. Finish filling with water until you are



see the level of liquid through the filler neck, leaving just enough room for expansion. Put back the radiator cap, and run the engine a few minutes until the heat indicator shows normal operating temperatures. Stop the engine and check your coolant level again. You may need to add more water.

If your days are getting shorter and you feel a nip in the air, and you leave the temperature on its way down — then you passed, and hence, cylinder glass eye, it is colder. Fill the system about one-quarter full of clean water and dump in enough inhibitor for the lower expected temperature. There's a

dash in your FMJ. Add more water, again leaving room at the regular coolant expansion. Start the engine and run it up to its normal temperature. Shut it off and add more, if needed, up to the coolant level for your particular vehicle — see higher. Another good idea is to make a copy of T-78-28, 29 & 30 answer any of the questions you may have on anti-freeze installation.

HEAT-CHECK

Just because leaks haven't been mentioned, don't assume there won't be any. Keep your good eye open for leaks anywhere in the cooling system, anytime during this whole operation.

The clearing solution may show some leaks in pouring, so it may expose what leaks previously plugged tight by the rust and corrosion. Naturally you will fix or repair all leaks — whichever you have here.

If you go to work on this clearing business, and also get particular about what goes into the radiator and what (if anything) leaks out of the hose — there just won't be any more of those rubber-ringing high low-higher solution with a sticking cap.

At this point it is recommended that before winding you up from a cap of water with, and mean that you will avoid hot dreams about cooling systems.

And there you are.





Dear Half Mast:

Should the front wheel bearinging on a GMC Truck fit so tightly on the steering-knuckle assembly, as the factory facts sheet says, so tight that bearings be able to slide freely, having approximately .010" clearance between the bearing case and the steering-knuckle assembly?

Would also like to know if the front-wheel later-bearing oil seal (508-381100) is interchangeable with the sealers (508-38111) and (508-38112) on the Tucker front axle?

Sgt. J. W. W.

Dear Ferguson,

The right fit for the front-wheel later-bearing case on the front-axle spindle should be a "snug" fit — to let the case creep slightly around the spindle when you're loading a specially heavy load. That way, the bearing surface area that gets the load is changed a little at a time, so it wears even. Trucks run in production have either a slight press fit or an easy push fit on the spindle, depending on who builds 'em. But if you're substituting a real front axle, you could have the bearing-spindle diameter .002" smaller than the inside diameter of the case. It should never be .010", though, because that much would bring the bearings and

the spindle.

As for interchanging the front-wheel inner-bearing oil seal, and the kit and retainer — I wouldn't do it, Sarge. It's physically possible, but unless the sealing surface of the axle supports spindle is polished after the retainer is removed, to provide a smooth surface for the seal lip, the seal will wear out long before its time.

HALF-MAST

Dear Half Mast,

We've had a lot of inner springs break on our FV's (see GMC's), so we had inner-helix Chevrolet rear springs and put them in on our GMC fronts. Also added two of these springs to the original axle frame on the truck. This made the riding right's handle, but it influenced the handling. We suggest GMC springs to match FV's with eleven leaves. What do you think?

(508-3811)

Dear Mr. G.

I look at it this way: With the 1941 springs 124" wide, they probably wouldn't break when the truck's jostling, even rough terrain — but, other parts would creep and break, such as frame and axle assemblies. Since the part has to be full width and "shock-absorbent," and that part's the front springs.

Manufactured from heavy, hollow steel leaf springs, may be stretched or have slight cracks you can't see — and when they're used to adjust springs, they'll stretch spring life instead of preserving it. Be sure old leaves should be checked thoroughly with a wire brush or buffer, and a good oil dress to seal over them for life.

Did your leaf manufacturers say that may help your springs?

(1) Tighten spring clips and U-bolts regularly, and be sure they both are used as directed from factory drawings (even being properly tightened).

(2) Over-tightening the shock's bolts'll cause the leaves to break near or at the spring eyes. Drive the nuts up as tight as possible, then back them off one-half turn so they don't bind.

(3) Drivers or did on the leading edges, loose leading plates or a quick stop at the curb (like the front wheels like a deep rut or hole, will set up all kinds of spring deflection.

(4) Two different springs, with different carrying capacities, are used in 1947-48 GM's GM20-40000 is one front-spring assembly that carries 1000 lbs. — it's used on trucks without which GM 14000 carries 1000 lbs. and is used on cars with weak.

(5) Keep the coil-to-frame hanger bolts in good shape, so they'll fit the springs as they fit in reverse number ones.

(6) Don't lubricate spring leaves, as Freuden said before — the lubricates away the friction between the leaves and reduces their load-carrying ability. Some-time grease gets into spring leaves from new lubing the spring-axle bolts, with the little bit result.

And (7) Read "GM'S SPRING" on page 28 of the June P 5.

HALF-MAN

Dear Half-Man,

On two different occasions we've had 75-ton GMC's but their left rear wheels. Whether it was due to the negligence of the mechanic (failing to look the back wheel or whether the last one part of the trailer broke, affecting the rest to follow, I don't know). But as usual things made, why don't manufacturers make the trailers and axles with left-hand threads, so it either of those things happens, the driver will tighten instead of come loose?

Ed. W. W.

Dear Edward,

It looks from your letter you are blaming the loss of those two left-hand wheels on the driver or mechanic. Because if the mechanic had looked the adjusting nut properly in the first place, it should stayed put. And if the nut did come loose, the driver should noticed an excessive of brake drag and pulled about it before anything else had a chance to happen.

As the industry and speaks with left-hand threads, the manufacturers did say that more, but they stopped making 'em because the longer that sometimes with the nut loose can (be what it was right if it isn't looked correctly. They'd more found and overhauled bearings and they, the way it is, don't fit in many parts to be standard and not standard, and you get interchangeability in the hospital.

It might help you to know that there are various types of GM's wheels used to bolt the wheel-rotating nuts securely — these different types are GMC's also. First, there's GM 14000, which is preferred, and looks the adjusting nut when the bolts in the wheel line up with the driver pins in the nut and the lower nut runs in the spindle groove. Next is GM 14000, this is a split-type nut, and looks the adjusting nut by looking the inside half (and part of the outer half) of the wheel nut the nut, with the nut,

in the spindle groove and the locknut, pulled up right against the washer. Then loosen the EMM-10000996, with some special nutting the outer edge and run in the locknut which lies in the spindle groove. The nut is locked by bending the stretch-strap in the center of the nut. All done?

WALF BLATT

Dear Wolf-Blatt,

Many a job on Willys bugs we've run into and puzzled over—what's what adjustment?

When all adjustments were made and everything was correct, if the steering wheel was placed in position for the alignment of your truck, the front wheels were 2 degrees, more or less, away from the straight-ahead position they should be in. Moving the steering arm two spots on the lower plate changed the steering wheel this much 12". We've tried to correct an error of about a half a degree, an average of 2" measured at the steering wheel rim, at 7.10" or less of drag-link travel.

This was the adjustment procedure we followed: Disconnected the drag-link, checked the detentive springs and ball joints, or phorax half-rod, checked the springs that at the dash, adjusted the lower bearing and nut at the cross and nutting, single shaft started the steering wheel's lower rim for the old point of gear mesh, and adjusted the nutting in the dash. Then we adjusted the ball-rod-plate nut and also the nut in adjusting ball rod nut to front only, checked the front end of the drag-link for shivers and proper adjustment, connected the rear of the drag-link to the steering arm, placed the front wheels in straight-ahead position, and double shaft started the steering wheel's lower rim for straight-ahead of the front wheels.

In many cases, the two different shaft marks were from 2" to 3" apart. And there's our problem.

We've checked our ball rod and phorax more for bend, and measured the drag-link for run-in—only got a number of times and never found any defects. Several ball rods and phorax nuts, if needed because of worn ballrods, were tested in the alignment press.

A lot of questions come back, but what prevents is the correct adjustment to this problem. If you're bothered by this too, even if you can't do any more and give the to highest standard for your job, please, Continued Maintenance Service.

July 29, 1

Dear Continued Maintenance,

Service Shop No. 1.

You may give me plenty of ideas, and I've checked your problem all the way from the axle to the seat.

There's still another angle you can work on. The records could be properly adjusted when spacing the ball rods to the axle (see TM 7-203, page 187). And it seems to me, if you're steering gear is at the midpoint, the drag-link attachment and the wheels 2 degrees away from the straight-ahead position, you should be able to adjust front ballers of your tie-rod-ends to maintain the wheels.

WOLF-BLATT

FREE! FREE! FOR THE AUTO!

It is now yours for the asking! Through careful investigation with records in particular, *WOLF-BLATT* is offering free personal subscriptions to those men to people who ask good, pertinent questions. Are you up to the level of this problem? Do you feel yourself an maintenance man without any one? Write your burning questions to "Dear Wolf-Blatt," P.O. Box 10000, Detroit, Michigan, Detroit, Michigan. May-land. If they're important enough to be published, you'll get a personal subscription. Even if they're not, you'll get an authoritative answer.

HOW THAT YOU'VE SEEN 3 ISSUES HOW ABOUT YOU SOUNDIN' OFF!



Let's hear from you! If Magazine has a big job to do—and if we can't please anyone, we'll try to come up with that.

What are your plans and interests? Why not let Mail-Order know that problem you're facing along with this magazine with it in hand — tell him your trouble.

And if you've got a bright idea, or built a better mousetrap, don't forget it. Same with a, same time when it comes to doing even the same job. If your idea's good, we'll give it along and you'll even yourself a treat, one-year personal subscription to *PI Magazine*.

There's only one place we make when you write — give us the facts. Include things like Manufacturer's name, article number, part name, size, shape. Detail the trouble — how did it happen, when, under what conditions, how about full or low and why and where and what and what-not about your solution. If you've got a picture or can describe one, show it along.

Keep about three and four — you can write on T. F., as long as it's complete. Then — if we get all the facts — we'll get some intelligent results.

**IF YOU CAN WRITE, DRAW
A STUFFY PENCIL —
SIGNED, SIGNED AND
JOINED — PUT IT OUT,
SHOW IT IN AN ISSUE,
OH! AND SEND IT TO PI
IMAGINE, A BUNCH
PROVING, DROPPING,
AND YOU'LL SURE APPRE-
CIATE IT!**

SEND NO MONEY

ONE IS A BUNCH!

You can help a lot by answering these questions.

1. When did you get the issue of *P. I. Magazine*? _____
2. Did you get the magazine from the Street Station, the Co-Op Store, or the Street Magazine, or where? _____
3. Do you think you might have been getting enough copies? And if not, how many more do you need? _____
4. Did you know that Charles E. Hooper is *PI*'s editor? Do you think he's doing a good job for *P. I. Magazine*? _____
5. What did you find in this issue, or other issues, that helped you in some way — told you something that maybe you didn't know before? _____
6. Is there something special you'd like to see in *P. I. Magazine*, some article you think would be useful? _____

*Section 9, Part 1, which deals with using your pen.

*Editorial boards of the United States, which will be available in *Address General Edition*. See above to find address of *PI Magazine*.

NAME _____

ORGN _____

APD No. _____

40¢ POSTAGE

SEND NO MONEY

THIS OFFER IS ONLY AVAILABLE TO NEW SUBSCRIBERS

The condition of things arriving at the ports the previous day must mean they're going to mean the impression that everybody's got to own private copies of Supply Bulletin should have. And as far as it was known, only one vendor was listed.

"If something else comes along to take its place, you'd do well to use it instead of paper even when we have to pack and store things — if you're really committed to get your goods to the battlefield in a flash-light or flash-cut condition. If it's not in 5-4, use your good common sense especially on the items mentioned below. Unless the matter is more packable than that", ... if it's not right, they'll do it at the port."

TABLE IV. HOW CLOSE TO

MILITARY PACKAGING



BETWEEN THE LINES

LETTERS FROM ALBANY

Dear Editor,

You were quite right in your article about the
College Rule. A friend of mine over-
saw 'em talking and he got the impression, etc.
comes this and state of affairs by using a
And you're so right, but even though they were
like pencil. He was 'hard-headed' to make sure
in our own country. The first mistake, for "what
his own recent acquisitions equipment they
all" to work with some utilized to be. On top of that
really don't need. Calling for new and/or rebuilt
normal supplies this time, we've got 50 new motor
engines in the way, all taken only one good
reliable engine (maybe two or three) for the same.
And to tell of a request for major overhaul can
be handled by a set of new plugs, or new pistons,
should get in detail of the whole business when the
a conference, a sharp line-up... at the next major
start is mounted, they'd have well rather see a few
ways and pins. Enough of these parts for half-
price, and a machine to get them in. And
of it. Technical' deadline wouldn't wait as
you can't ride anything on a bank of ten when you're
much as one engine. How long can you hope to
make out their writing. Maybe you think that's
over, his new would have athletic equipment,
balls around here's a lot better? Right, so here,
and the night could get shorter.

Ed. Kelly, Rochester



BETTER

than a

P.S.

slip!

DA AGO Form 888 (Satisfactory Equipment Report, above) will do you more good than a P.S. Slip. Here's the chance for you folks who've been crying and howling "I couldn't do a better job of building this B-70 if I did" & "to bring this thing back!"—to get up or shut up. Form 888 gets your complaints back to the people who can and will do something about it. Just give 'em the facts. Report checks statements or details in anything — vehicles*, guns, or any old hardware, large equipment peculiar to the AF not included. Fair wear and tear doesn't count.

If you need the results, don't keep the form you did it on yourself—send it along via Form 888. It might help either gathering facts — it might be good enough to interpret — in production.

*When it's vehicles,

write us, too